Assembly Instructions CAT TOWER WOODEN

CARE INSTRUCTION: Wipe clean with a soft dry or damp cloth. Keep away from water and direct sunlight. For indoor and domestic use. Check and tighten all parts regularly.

WARNINGS: Do not stand or sit on the unit. Do not lean on the product. Do not drag the product. Use only on a flat surface. Do not use until all screws, bolts and knobs are firmly secured. Load the drawer evenly to prevent it from tipping over. This product contains small parts and sharp points, keep away from children and babies.


Adult assembly required. Failure to follow these warnings could result in serious injury.


MAXIMUM TOTAL LOADING WEIGHT: EACH SHELF:15kg (MAXIMUM).


Hardware list


TA TA	а		5PCS
	b		5PCS
	С	6X30mm	10PCS
8 Tunnama	d	4X40mm	10PCS
B liman	Ф	3.5X12mm	12PCS
0	f	5X25mm	17PCS
0	g	6X30mm	2PCS
S. S	h	4X12mm	1PC
	i		2PCS


O	j	6X12mm	8PCS
6	k		2PCS
	l		2PCS
	m		1PC
O Traver	n		1PC
& Managaran	0	4X32mm	1PC
1 Managana	р	7X50mm	8PCS
	u		1PC






















Warning:

- · ALWAYS secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors.
- Do not place unanchored televisions on furniture.

Caution: for your safety when attaching the anchor fixings, please note the following:

• Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson)



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.








A WARNING







Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.











STEP 26


Option 2














STEP 34











Warning:

- · ALWAYS secure it with an anchor device.
- · Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- · Stability of tall items may be affected by thick pile carpet or uneven
- Do not place unanchored televisions on furniture.

Caution: for your safety when attaching the anchor fixings, please note the following:

· Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson)




WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.












Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture


This is a permanent label. Do not remove!




Hinger Adjustment Tips

Noted: The door might be scraping, bumping, misaligned when first assembly.

Please follow the below tips:




Adjust the door up and down



- 1. Loosen the two mounting screws on both hinges, but only slightly. ...
- 2. Gently close the cabinet door.
- 3. With the door still closed, adjust the cabinet door to the desired height.
- 4. Open the cabinet door again, being careful not to jostle the door out of position.
- 5. Retighten the screws by hand.




Move the door in and out



If the door doesn't meet the box at the top, adjust the top hinge toward the cabinet and/or adjust the bottom hinge away from the cabinet. If the door is gapped at the bottom, do the reverse.



Move the door right or left



You can adjust one or both hinges on each door, depending on how much correction it needs. If the door seems to be tilting down to the right, turn the side-to-side screw on the top hinge so the hinge pulls closer to the side of the cabinet box, moving the top of the door to the left.