



MULTI SNACK MAKER

Instruction Manual



Model No.: AMSM504

Rev 01


To ensure the proper operation of this device, please read this instruction manual carefully before using the device and keep them for further reference.

EXPLANATION OF SYMBOLS

The following symbols and signal words are used in this user manual, on the appliance or on the packaging.



This signal symbol/word designates a hazard with moderate risk, which may result in death or severe injury if not avoided.



This signal symbol/word designates a hazard with low risk, which may result in minor or moderate injury if not avoided.



This signal word warns of possible damage to property.



This symbol provides you with useful additional information about assembly or operation.



This symbol identifies that the material used in the product is safe for food contact.

IMPORTANT SAFEGUARDS



Read all instructions thoroughly before first use, even if you are familiar with this type of product. The safety precautions mentioned in this manual reduce the risk of burns, fire, electric shock, and injury when correctly followed. Keep this manual in a safe place for future reference, along with the purchase receipt and packaging. If applicable, pass these instructions on to the next owner of this appliance.

When using electrical appliances, to reduce the risk of personal injury or damage to property, basic safety precautions must be observed including the following:

- **Usage restrictions:** This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- **Children:** Supervise children to ensure that they do not play with the appliance. Close supervision is necessary when any appliance is used by or near children. Keep the appliance and its cord out of reach of children.
- **Voltage:** Make sure that the outlet voltage and circuit frequency correspond to the voltage stated on the appliance rating label. If it does not match, do not use the appliance.
- **Exclusive outlet/separate circuit.** Insert the plug securely into a properly earthed mains socket that is within easy reach so that the plug can be easily removed if necessary.
- **No timer:** Do not connect the appliance to an external timer or a separate remote-control system.



Do not immerse!

To reduce the risk of electric shock, do not immerse the cord, plug or appliance in water or other liquids. If it falls into water, immediately unplug it from the electrical outlet. DO NOT touch it or reach into the water to retrieve it.

- **Protect from moisture:** **DO NOT** expose the electrical connection to water. **DO NOT** use the appliance or touch the plug with wet or damp hands, on a damp floor or when the appliance itself is wet. **DO NOT** spill liquids into or on the product.
- **Electrical safety:** Do not insert any objects into the appliance.
- **Protect the power cord:** Do not kink, squash, or strain the power cord and protect it from sharp edges and heat. Do not let the cord touch hot surfaces, including the cooking surfaces, when it is in use. Do not place anything on top of the cord. Do not wrap the cord around the appliance and never pull the cord to lift, carry or unplug the appliance.
- **Power cord:** A short power cord is provided to reduce the hazards resulting from entanglement or tripping over a longer cord. If it is necessary to use an extension cord, make sure it has been approved and has the same or higher electrical rating (voltage and power) as the product (check on the rating label underneath). Arrange the extended cord so it will not drape over the table or bench-top where it can be pulled on or tripped over accidentally.
- **Damage:** Check the power cord regularly for visible damage. If it is damaged, do not use the appliance.



Do not use when damaged!

Do not pick up or operate an appliance with a damaged cord or plug, or after it malfunctions or has been dropped or damaged in any manner.

- **Disconnect:** Always turn the power off at the power outlet before you insert or remove a plug. Unplug the appliance before cleaning, servicing, maintenance or moving the appliance and after use. Grip the plug when disconnecting, do not pull on the cord.
- **After use:** Wait until the appliance is unplugged and has cooled completely before cleaning, maintenance or moving the appliance.
- For electrical safety, if the supply cord is damaged, it must be replaced by a qualified electrical person only or the product must be disposed.
- **Domestic use only:** This appliance is intended for private domestic use only. It is not suitable for commercial, industrial or trade use. Do not use it outdoors.
- **Proper user**

This product is exclusively designed for making doughnuts, waffles, and pancakes. It is only intended for private use in houses and similar applications such as:


- Staff kitchen areas in shops, offices, and other working environments.
- Farmhouses.
- By clients in hotel, motels, and other residential type environments.
- Bed and breakfast type environments.
- **Intended purpose:** Do not use the appliance for anything other than its intended purpose and only use it as described in this manual. Any other use is not recommended and may cause fire, electrical shock, or injury.
- **Accessories:** Do not use accessories that are not supplied with this unit. The use of accessories that are not recommended or sold by the manufacturer can cause fire, electrical shock, or injuries.
- **Flammable materials:** Do not use the appliance in the close vicinity of flammable materials such as curtains, drapes, paper, wall coverings, tea towels or clothing. Do not use it under a cupboard or close to a wall as scorching may occur.
- **Work area:** To ensure efficient operation and avoid overturning, always place the appliance on a level and stable, heat and flame-proof work surface. Do not use it on an inclined plain or unstable surface. Always ensure that there is sufficient free space above and around all sides of the appliance for air circulation.
- **Protect from heat:** Do not place the appliance on or near a hot gas or electric stove/cooktop, or near a heated oven.
- **Keep clear:** Never place anything on top of the appliance while it is in use or still hot.
- **During use:** Do not move the appliance while it is in use. Do not cover it when it is in use. Food may burn, so always monitor the cooking process when using the appliance.
- **Utensils:** Only use wooden, silicone or heat resistant plastic utensils to remove food from the cooking plates (moulds) of the appliance. Do not use metal utensils to avoid scratching the non-stick surfaces.
- **Storage:** Do not leave any cardboard, plastic, paper or similar in the appliance.
- **Cleaning:** Always remove the plug from the socket before cleaning the appliance and let it cool down until the cooking surfaces are safe to touch. Only clean the non-stick moulds (cooking plates) with a soft brush or damp cloth to avoid damaging the non-stick surfaces. Do not use abrasive or harsh cleaners.

- **Repair:** The appliance has no user-serviceable parts contained inside. Do not attempt to repair, disassemble, or modify it yourself.
- **Liability:** Misuse or improper installation may result in the risk of fire, electric shock, and/or injury. We assume no liability for any eventual damage or injury caused by misuse of the product or non-compliance with the instructions.



Do not leave unattended during use.

Always switch off the appliance and unplug it from the power supply.



Caution Hot surfaces!

Do not touch hot surfaces! The appliance generates heat and escaping steam during use. Take proper precautions to prevent the risk of burns, fires or other injury to persons or damage to property.

- Accessible parts of this appliance get hot during operation and retain heat for some time after turning off. Always use the handles and oven mitts or similar when handling hot materials and allow metal parts to cool before cleaning. Keep the power cord away from hot parts.
- Regarding the instructions for cleaning surfaces in contact with food, refer to the “Cleaning and Maintenance” section.
- Do not leave the product unattended while in use.
- The outer surface may get hot when the appliance is operating.



- To reduce the risk of electric shock, do not immerse or expose the product, flexible cord or plug to rain, moisture, or any other liquid.
- Do not use the product near bathtubs, showers, basins, or other vessels containing water or other liquids, or when standing in or on damp or wet surfaces.
- In the event that the appliance is dropped into water, turn off the power at the power outlet and remove the plug immediately.
DO NOT REACH INTO THE WATER TO RETRIEVE IT UNTIL IT HAS BEEN DISCONNECTED FROM THE POWER OUTLET.
- It is important to note that the appliance will have to be inspected by a qualified technician before using it again.

SAVE THESE INSTRUCTIONS

PRODUCT OVERVIEW



1. Power on/Ready indicator lights
2. Cool touch handle
3. Locking latch
4. Plate release switch (top and bottom plates)
5. Upper housing
6. Base housing
7. Interchangeable waffle plates
8. Interchangeable doughnut plates
9. Interchangeable pancake plates

BEFORE FIRST USE

Carefully unpack the appliance and remove any packaging. Place the unit on a level, dry and heat resistant surface ready to use. Ensure to read all instructions carefully and keep them for future reference.

1. Wipe the non-stick coated plates with a slightly damp cloth prior to first use to remove any dust and residue.

NOTE: Do not use any abrasive cleaners as these may scratch the non-stick coated plates.

2. Clean the outside of the appliance with a warm damp cloth. Wipe clean with a dry soft cloth. Abrasive cleaners and scourers will damage the appliance and must be avoided.



DO NOT IMMERSE THE APPLIANCE IN WATER. DO NOT RUN WATER DIRECTLY ONTO THE NON-STICK COATED PLATES whilst the plates are still in the appliance.

3. Condition the non-stick coated plates for long-term protection. Carefully spray or spread a little vegetable oil onto the preheated plates using a silicone brush or paper towel.



HOT SURFACES! Exercise care, as the cooking surfaces will be hot. Leave the coating on the surfaces but wipe off any excess with a paper towel.

4. Close the snack maker.
5. Connect the appliance to the mains socket outlet and turn the main switch on. Allow the appliance to heat up for approximately 5 minutes.

NOTICE!

When the appliance is heated for the first time, it may emit a slight amount of smoke and smell, but this is no cause for concern, it is due to the elements and components being new. Ensure there is good ventilation.

6. Unplug the appliance and let it cool down completely.

CHANGING THE NON-STICK COATED PLATES



Always unplug the appliance and allow it to cool completely before removing or changing the plates.

1. Undo the locking latch (3) and open the upper housing (5). Locate the plate release switch (4) on the upper and base housing.

2. Push the plate release switch (4) to the direction of the arrow to remove the plates. Remove one plate each time.

Note: Please be careful as the plate will spring out if both release switches are pushed at the same time.

3. Grasp the plate with two hands, lift it out of the housing.



4. To put a plate into the appliance, first insert on the hinge side and then press down on the plate near the centre of the handle until the release switch engages.



USING THE MULTI SNACK MAKER

PREPARATION

1. Place the appliance on a level and stable, heat/flameproof work surface, with enough room for ventilation all around it and close to an electrical outlet.
2. Select a recipe for your chosen plate (waffle, doughnut, or pancake).
3. Prepare the recipe and have the batter ready to use.

PREHEATING

1. Ensure the upper housing (5) is closed. Insert the plug into the mains power supply and switch on the power at the wall outlet. The RED and GREEN power and ready indicator lights will illuminate indicating that the appliance is on and preheating.
2. After a few minutes, when the GREEN indicator light (1) turns off, the appliance is ready to use. The green indicator light will cycle off and on as the thermostat in the unit maintains the correct operating temperature. Always keep the upper housing closed when preheating or in-between uses.

USING THE APPLIANCE



HOT SURFACES! Take the utmost care when using the appliance, the cooking surfaces get very hot! Do not touch any metal surfaces until the unit has cooled completely.

1. Using an oven mitt or potholder to prevent accidental burns, unlock the handle locking latch (3), grasp the handle, and raise the upper housing (5).
2. Place your batter onto the corresponding plate, close the upper housing (5) and allow to cook according to the approximate cooking time on the recipe.



HOT STEAM! Steam may be released between the non-stick plates whilst cooking is in progress. Caution should be taken to prevent hands from coming into contact with the steam.

3. The GREEN indicator light (1) turns on and off as the appliance maintains the ideal cooking temperature, this also prevents overheating.
4. After the cooking time has completed, grasp the handle, and open the upper housing (5). Determine whether further cooking is required. If so, close the housing and allow to cook for another minute before opening again.
5. Use a heat proof plastic or wooden spatula to remove your cooked food from the non-stick plates.

NOTICE!

Do not use a knife, fork, or any other sharp or metal object when removing foods from the cooking plates as this will damage the non-stick surfaces.

6. Cooking times will vary depending on different ingredients used and the individual's personal preference. Cooking times stated in the recipes should only be used as a guide.



Always take care when biting into freshly cooked foods as this may burn your mouth.

7. When you have finished, switch off the power at the outlet, unplug the appliance and let it cool down completely before cleaning, see section "Cleaning and Maintenance".

TROUBLESHOOTING

Problem	Solution
Smoke is coming from the appliance when I plug it in.	If you are using the appliance for the first time, this is normal and no cause for concern. If you are not using the appliance for the first time, check and ensure that the moulds (cooking plates) are clean, and no food particles are baked onto the plates. If it continues to emit smoke, do not use.
The appliance is not heating.	Check that the red power indicator light is illuminated. Check that the appliance is turned on at the mains switch. Check the household circuit breaker/safety switch.
How do I know the plates are hot enough?	When you connect the appliance to the power supply, the red and green indicator lights will illuminate. The appliance is ready for cooking when the moulds (cooking plates) are pre-heated, and the green indicator light turns off.
The food is not cooked after 4-5 minutes.	Close the lid gently and cook for a longer period, regularly checking the progress.
Do the plates have to be locked together during use?	Yes, closing the lid and clipping the handles together ensures that the batter is safely enclosed in the moulds (cooking plates) during baking.
Batter has spilled out and is sticking to the edges of the cooking surfaces. How can I remove this?	Switch off the power at the wall outlet, unplug the appliance and let it cool down completely. Use a nylon brush to remove any baked-on batter residues or another utensil that is safe for use on non-stick coated surfaces. If this does not work, use a damp cloth or sponge and a small amount of detergent to soak and wipe the spillage off the cooking surfaces.

NOTICE!

It is important that you do not use metal utensils, which will damage the non-stick coating.

RECIPES

NOTICE!

Cooking times are for reference only.

Always monitor the food while it is cooking.

WAFFLE PLATE

PREP TIME: 15 Minutes

COOK TIME: 3-4 Minutes

Ingredients

- 150g self-raising flour – sifted
- 1 tsp baking powder
- 1 tsp caster sugar
- 250ml milk
- 1 egg
- Butter for cooking – for greasing the waffles plates if required

Method

- Insert the waffle plates into the appliance.
- Preheat the appliance until the green indicator light turns off.
- In a large bowl, put the sifted flour, baking powder and caster sugar and stir gently to combine.
- Make a well in the middle of the dry ingredients and crack in the egg, add a little of the milk and using a wooden spoon, stirring in small circles, gradually mix the batter together, adding more milk whenever the mixture becomes stiff.
- Stir until the batter is smooth and free of lumps.
- Gently pour the batter onto the waffle plates. DO NOT overfill.
- Bake the waffles in the preheated appliance for 3-4 minutes or until golden brown.
- Close the lid and cook for a longer time if required.
- Once cooked to your liking, carefully remove with heat resistant tongs or a spatula. Allow the waffles to cool on a wire rack. Repeat the process again until the remaining mixture is used up.

Makes approximately 2 waffles.

DOUGHNUT PLATE

PREP TIME: 10 Minutes

COOK TIME: 2.5-4 Minutes

Ingredients

- 250gm Flour
- 125gm Granulated sugar
- 3 tsp Baking powder
- 1 Large egg
- 108ml Milk
- ½ tsp Vanilla extract
- 4 tbsp Oil

Method

- Insert the doughnut plates into the appliance.
- Preheat the appliance until the green power indicator light turns off.
- Combine the flour, baking powder and sugar in a large bowl.
- Add the egg, vanilla and milk and whisk for 1 minute with an electric mixer or vigorously by hand.
- Add the oil and continue to whisk for a further 1 minute.
- Pour a tablespoon of mixture into the preheated appliance. DO NOT overfill.
- Close the lid and cook for 2.5-4 minutes depending on how well cooked you like your doughnuts. Close the lid for further cooking time if required.
- Carefully remove with heat resistant tongs or a spatula. Allow the doughnuts to cool on wire rack. Repeat the process again until the remaining mixture is used up.

TIP: Brush the cooked doughnuts with melted butter or dust with sugar or a topping of your choice.

Makes approximately 18 doughnuts.

PANCAKE PLATE

NOTICE!

You may be able to purchase a ready-made pancake mix to use in the appliance. The ready-made mix will allow you to prepare, mix and pour in a convenient bottle.

BANANA PANCAKES

PREP TIME: 10 Minutes

COOK TIME: 5-6 Minutes

Ingredients

- 1 Egg
- 1 cup milk
- 1/3 tsp salt
- 1 ½ cup flour
- 1 ½ tsp baking powder
- 2 very ripe bananas

Method

- Beat the egg, add the milk and other ingredients in the given order and beat them well.
- Ensure that the mixture is well combined, before pouring it into the pre-heated appliance. Brush some oil or melted butter over the surface of the moulds (cooking plates). Pour the mixture into the appliance, DO NOT overfill.
- Close the lid and cook for 5-6 minutes depending on how well cooked you like your pancakes. Close the lid for further cooking time if required.
- Once ready, carefully remove with heat resistant tongs or a spatula and place the cooked pancakes on a plate. Repeat the process again until the remaining mixture is used up.
- Top with your favourite syrup, topping or fruit.
- For a large family, double or triple the above ingredients.

Makes approximately 5 pancakes.

CLEANING AND MAINTENANCE



Ensure that the appliance has been disconnected from the power outlet and has cooled down completely before cleaning or storing. Never immerse the appliance, power cord, or plug in water or any other liquid. Never place it in a dishwasher. Never run water directly onto the moulded plates (cooking plates).

Do not use harsh or abrasive cleaners or cleaning materials (such as steel wool, scouring pads or oven cleaners) on any part of the appliance. They will damage the non-stick coating of the cooking plates and affect the finish of the appliance housing.

- In order to prevent food residue build up, clean the appliance after each use. Use a damp cloth or brush to remove any crumbs or baked on foods from the surfaces. Do not use water to clean the plates. Ensure that no moisture or oil enters the appliance. Dry thoroughly.
- To remove stubborn stains or baked on residues, use a nylon brush or other utensil safe for non-stick surfaces. Do not use steel wool or scouring pads. Do not use abrasive cleaners.
- Wipe the exterior with a clean, damp cloth. Dry thoroughly.

STORAGE

- Ensure that the appliance has completely cooled and is clean and completely dry before storing. Close the lid and lock the handles together.
- Place the appliance in its original packaging and store in a clean, dry place out of the reach of children.

NOTICE!

If the appliance is damaged, do not attempt to repair it yourself. Any repairs to the product must be performed by a qualified electrical person only or the product must be disposed of.

TECHNICAL DATA

MODEL:	AMSM504
SUPPLY VOLTAGE:	220-240V~ 50-60Hz
POWER CONSUMPTION:	650W

12 MONTH WARRANTY

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

The warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expenses incurred in returning this product can be addressed with the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/-Customer Service Centre 690 Springvale Road, Mulgrave VIC 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, VIC, 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us