

# Safety Tips for using the microwave



Check the food container is microwave safe. Do not use a non-microwave safe container as it may explode or cause sparks or fire.



Do not cover or block the vents on the microwave. This could cause overheating and damage the microwave.



Make sure packets or sealed containers are opened before heating in the microwave, as they could explode.



Do not cook eggs with shells in the microwave, they may explode.



Use a low power setting when heating dry food or food with low water content. To prevent melting, do not use a container that cannot withstand a high temperature.



Liquids or foods must not be heated in sealed containers. Food expand when heated. Do not over-fill, leave a gap of at least 3.5cm between containers to avoid food spillage.

**ATTENTION!**

**KEEP CLEAN**



Clean after use. Build-up of spilt food can damage the microwave due to excessive burning.