

# Assembly Instructions

K: 43631759 | T: 71771878 10L Motion Sensor Bin

## Warning:


1. Battery: 2 x 1.5V AA batteries.
2. Non-rechargeable batteries are not to be recharged.
3. Different types of batteries or new and used batteries are not to be mixed.
4. Batteries are to be inserted with the correct polarity.
5. Exhausted batteries are to be removed from the appliance and safely disposed of.
6. If the appliance is to be stored unused for a long period, the batteries should be removed.
7. The supply terminals are not to be short-circuited.
8. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
9. Children should be supervised to ensure that they do not play with the appliance.

## Operation Instructions:


1. Install and remove the batteries.

1.1 Open the battery cover on the underside of the bin lid and insert 2 x 1.5V AA batteries into the battery casing. Please make sure the batteries are to be inserted with the correct polarity. Close the battery cover and ensure it is secure before use.


- 1.2 When the batteries are exhausted, should be removed from the battery casing and safely disposed of.




Step 1. Find the position of Battery



Step 2. Open the lid



Step 3. Put into AA battery




Step 4. Close the lid

## 2. Sensor Mode


2.1 The lid will automatically open when your hand or other objects is detected within 15CM( $\pm 5$ CM) above the sensor area ; If there are no obstructions detected within the sensor area, the indicator panel will display a countdown of 5 seconds; After the countdown finishes, the bin lid will automatically close.

2.2 If there is something blocking the lid from closing, please remove the object and wave your hand above the sensor area to open the lid, the lid will automatically close after 5 seconds.

2.3 The lid will remain open when object is detected within the sensor area. The lid will automatically close after 5 seconds when the sensor area is clear.



Indicator Light   Receive Signal   Transmit Signal



## Maintaining:

1. Please keep the product away from fire.
2. Please use genuine high-performance alkaline batteries.
3. In order to prevent false trigger sensor, please keep the vertical distance within 60-70CM above the sensor clear.
4. Please do NOT pour water directly on the sensor area.
5. Avoid using the bin in a moist or steamy environment.
6. If there is an automatic shutdown in normal use, it indicates that the voltage has dropped to 2.7V or lower instantly, and the system turns to the protection mode. Please replace the batteries.
7. During the opening and closing process, please do NOT apply external force to the lid (violently or quickly shake the lid back and forth), which will damage the motor gear and shorten the life of the bin.
8. In order to ensure the life of the product and protect the motor from damage, to open and close the lid by hand frequently is PROHIBITED.
9. The product is not suitable for being too close to high-frequency electromagnetic radiation products, such as refrigerators, induction cookers, etc., otherwise it may cause interference and affect the use of the product.
10. Please avoid direct strong light on the sensing area, which may easily lead to abnormal sensing sensitivity.