

Model no : VC8260-124

PLEASE READ AND SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

IMPORTANT SAFEGUARDS

- Indoors, as described in this user guide.

 A Aways waterful off and remove the otherger from the social before cleaning the applicance or any maintenanced task.

 It has applied an advantage of the property of the property

- 11. Use only attachments provided
 2. Static electricity some carpets can cause a small build up of static electricity. Any static discharge is not hazardous to health.
 3. Don of susk up liquidist
 4. Do not use your appliance out of doors or on any west surface or for west pick up.
 4. The contract of the contract of

- Do no spray with or pick up filammable liquids, cleaning fluids, aerosol
 Do no continue to see your appliance or charger if it appears fluily.
 Do not leave the appliance without the filters in place!
 Clinick his fluids are interested convery!
 Clinick his fluids are interested to a fluid and a fluid are interested and a fluid are interested and a fluid are interested as a fluid are int

WARNING: Do not recharge non-rechargeable batteries.

WARNING: Before charging the product, please make sure your hands are dry.

WARNING: Please don't touch the rolling brush with your hands when the machine is


WARNING: Please use the charger we supplied with the appliance. Other chargers may cause electrical failure and/or fire.

End of Product Life Battery Disposal

If the cleaner is to be disposed of, the batteries should be removed.

Used batteries should be taken to a recycling station and not disposed of with household waste. To remove the batteries, please proceed according to the following

IMPORTANT! Always fully discharge the batteries before removal and ensure the charger is unplugged.



- - M Dust cup release button
- E On/Off & speed switch N Dust cup
- G 2 in 1 crevice tool

until it locks into place. [1]



Align the brush head with the main body and firmly push into the main body until the brush head locks into place. [2]



and completely discharge battery. Afte first use, the normal charging time is 4hrs. The indicator light will blink when charging and remain steady when fully charged.



pressing the On/Off switch [E] on main

· Slow: Press once the On/Off switch · Fast: Press twice the On/Off switch.



Lift the handheld unit from the Main



Turn on the handheld unit by pushing forward the On/Off switch [K]



MORE ABOUT THE VACUUM

There are three indicator lights on top of the handheld unit indicating the state of charger. When the battery is fully charged, all

three indication lights will light up. As the vacuum cleaner is used, the

indicator lights will change from three to two, then two to one. The indicator will flash for around 20 seconds before the vacuum cleaner turn off automatically.

THE PRODUCT NEEDS TO BE CHARGED PERIODICALLY (2 or 3 TIMES A MONTH)
TO ENSURE OPTIMUM BATTTERY LIFE,
EVEN IF YOU HAVE NO INTENTION OF
USING IT FOR A LONG TIME



Empty the dust cup pull out the dust cup

Press the dust cup release button and



Pull out the filter



Empty the dust cup.



Cleaning the filter

Wash the filter and dust cup under running water



Leave to dry for 24 hours Make sure the filter and dust bin are dried thoroughly before fitting them back to the unit.

cleaned regularly for best suction performance and to prevent over-heating and damaging the vacuum cleaner



Cleaning the Rolling brush



H Brush head release buffor

vacuum stand, fold the handle and place it against the wall.



There is a wall mount accessory supplied with screws and wall plugs if you prefer to stand the vacuum cleaner against the wall.

To install the wall mount, position it on the wall and at a suitable height where can hold the handle. Mark the two screw holes through onto the wall using a suitable drill (wood drill bit for timber wall, or masonry drill bit for brick / concrete walls, drill three holes 26mm and 35 - 40mm deep.

Insert the plastic wall plugs into each hole and gently hammer in unell they are flush with the wall, place the hanging mount over the holes, then insert the screws and tighten up. Do Not Overtighten.





TROUBLE SHOOTING

Possible causes Solutions ocket/ charger jack if battery is fully charged 1. Brush head not correctly connected to main unit 2. The dust run is full 2 Empty dust cup 3. The filters are blocked 3. Wash the filter

Model number	V8260-12A
Battery	14.8V 2000mAh, Li-ion (x4 cells)
Working time:	Fast setting : 20-30min Slow setting : 30-40min
Charging time:	4-5hr
Battery charger	WJA-Y121750550W
	Input:100-240V 50-60Hz 24W;
	Output 17.5V d.c. 550mA

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in eccordonce with occompanign recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming

the warfang person. It was a second of the warfang. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or returnd for a major failure and compensation for any other reasonably forseesable loss or domanous. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases	
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landin, Vic. 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us	