

Assembly Instructions

43333158 KARLA ENTERTAINMENT UNIT

CARE INSTRUCTIONS:




















WIPE CLEAN WITH A DAMP OR DRY CLOTH. DO NOT USE ABRASIVE MATERIALS AND SOLVENTS. DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE OF THIS FURNITURE ITEM. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR AND DOMESTIC USE ONLY.

WARNING:














DO NOT STAND OR SIT ON THE UNIT. DO NOT KNOCK OR DRAG THE UNIT. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.

MAXIMUM SAFE LOAD:Top: 20kg ; shelf: 5kg .


1 Hardware List

	A	8x30mm	16pcs		B	7x50mm	8pcs		C		8pcs
	D	6x40mm	8pcs		E	15x11mm	8pcs		F	3x12mm	40pcs
	G		4pcs		H		2pcs		I		8pcs
	J		8pcs		K		8pcs		L		1pc
	M		5pcs		N		4pcs		O		2pcs
	P	4x40mm	2pcs		Q		4pcs		R		2pcs
	S	3x14mm	2pcs								

2 Parts List

							
①	1pc	②	1pc	③	1pc	④	1pc
							
⑤	1pc	⑥	1pc	⑦	1pc	⑧	4pcs
							
⑨	1pc	⑩	1pc	⑪	1pc	⑫	1pc
							
⑬	2pcs						


3




ATTENTION: DO NOT TIGHTEN THE SCREWS FULLY DURING ASSEMBLY. FULLY TIGHTEN SCREWS AFTER THE FINAL ASSEMBLY STEP.

STEP 1

A -  x 8 D -  x 8 E -  x 8




STEP 2




STEP 3


A -  x 8 B -  x 8




STEP 4 I - $\varnothing \times 8$ J - $\varnothing \times 8$ K - $\varnothing \times 8$ M - $\varnothing \times 5$




STEP 5 G - $\varnothing \times 4$ H - $\varnothing \times 2$ F - $\varnothing \times 12$




STEP 6

C -  x 8


F -  x 24




STEP 7



STEP 8 F - x 4 N - x 4 O - x 2 Q - x 2 S - x 2



STEP 9 P - x 2 Q - x 2 R - x 2



TOPPLING FURNITURE WARNING:

- It is strongly recommended that this product is permanently fixed to the wall.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).




WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.




Hinger Adjustment Tips

Noted: The door might be scraping, bumping, misaligned when first assembly.


Please follow the below tips:




Adjust the door up and down




1. Loosen the two mounting screws on both hinges, but only slightly. ...
2. Gently close the cabinet door.
3. With the door still closed, adjust the cabinet door to the desired height.
4. Open the cabinet door again, being careful not to jostle the door out of position.
5. Retighten the screws by hand.




Move the door in and out



If the door doesn't meet the box at the top, adjust the top hinge toward the cabinet and/or adjust the bottom hinge away from the cabinet. If the door is gapped at the bottom, do the reverse.



Move the door right or left



You can adjust one or both hinges on each door, depending on how much correction it needs. If the door seems to be tilting down to the right, turn the side-to-side screw on the top hinge so the hinge pulls closer to the side of the cabinet box, moving the top of the door to the left.