

Assembly Instruction

43554126 BURLEIGH ENTERTAINMENT UNIT

CARE INSTRUCTIONS:





















WIPE CLEAN WITH A SOFT DAMP CLOTH.DO NOT USE ABRASIVE MATERIALS AND SOLVENTS.CHECK AND TIGHTEN ALL PARTS REGULARLY.DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE.KEEP AWAY FROM WATER AND DIRECT SUNLIGHT.STORE IN A DRY PLACE.FOR DOMESTIC USE ONLY.FOR INDOOR USE ONLY.A MILD ODOUR MAY BE PRESENT WHEN FIRST OPENING THIS CARTON.SIMPLY ALLOW TO AIR OUTSIDE AND THIS WILL FADE.



WARNING:

DO NOT STAND OR SIT ON THIS UNIT.DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.DO NOT KNOCK OR DRAG THIS UNIT.USE ONLY ON A FLAT SURFACE. LOAD TOP EVENLY TO PREVENT FROM TIPPING OVER. THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


MAXIMUM SAFE LOAD: 25KGS FOR TOP, 5KGS FOR SHELF.

Hardware List

	A	6x35mm	8pcs		K	4mm	1pc
	B	15x10mm	8pcs		L		1pc
	C	8x30mm	16pcs		M		12pcs
	D	6x40mm	8pcs		N	3x16mm	12pcs
	E		4pcs		O	4x14mm	2pcs
	F	4x14mm	36pcs		P		4pcs
	G	4x18mm	3pcs		Q		2pcs
	H		3pcs		R	Ø20mm	13pcs
	I		2pcs		S		2pcs
	J		4pcs		T	4x35mm	2pcs
















Tools Required(Not Provided)





Do not tighten the screws fully during assembly.
Fully tighten screws after the final assembly steps.




Part List

			
①1 PC	②1 PC	③1 PC	④1 PC
			
⑤1 PC	⑥1 PC	⑦2 PCS	⑧1 PC
			
⑨1 PC	⑩4 PCS	⑪2 PCS	⑫1 PC
			
⑬1 PC			




Step 1:




Step 3:




Step 2:




Step 4:





Step 5:





Step 7:



Step 6:





Step 8:




Please refer to the last page of Hinger Adjustment Tips.

Step 9:



Step 10:



TOPPLING FURNITURE WARNING:

- ALWAYS secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture.

CAUTION: for your safety when attaching the anchor fixings, please note the following:


- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.



⚠ WARNING



Children have died from furniture tipover.


- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- ALWAYS secure your television with an anchor device or mount the television on a wall.

This is a permanent label. Do not remove!


Hinger Adjustment Tips

Noted: The door might be scraping, bumping, misaligned when first assembly.


Please follow the below tips:




Adjust the door up and down




1. Loosen the two mounting screws on both hinges, but only slightly. ...
2. Gently close the cabinet door.
3. With the door still closed, adjust the cabinet door to the desired height.
4. Open the cabinet door again, being careful not to jostle the door out of position.
5. Retighten the screws by hand.




Move the door in and out



If the door doesn't meet the box at the top, adjust the top hinge toward the cabinet and/or adjust the bottom hinge away from the cabinet. If the door is gapped at the bottom, do the reverse.



Move the door right or left



You can adjust one or both hinges on each door, depending on how much correction it needs. If the door seems to be tilting down to the right, turn the side-to-side screw on the top hinge so the hinge pulls closer to the side of the cabinet box, moving the top of the door to the left.