

Fitting instructions:

1. Carefully unpack the mirror and locate fitting instruction sheet, two hanging hooks and four self-tapping screws.
2. Place mirror face down on floor.
3. Using a ruler, measure down approximately 3cm from the top of the frame to locate the position of the top screw.
4. Using a Phillips head screw driver, attach hanger to frame with both screws.
5. Repeat process on second hanger.
6. Carefully hang your mirror on the top edge of door and enjoy!