



Mosaic Grout Instruction Manual

**Includes:**

- › white grout 250gsm
- › scraper

Instructions:

1. Mix 1 part water with 3 parts grout powder until smooth.
2. Using the spatula, spread the grout firmly into the gaps.
3. After 15 minutes, wipe away excess grout with a damp sponge.
4. Allow grout to dry for 24 hours.

Tips:

Protect work surfaces. Wearing gloves is recommended.
Ensure the surface is clean and dry. Use mixture within
15–20 minutes before it hardens.

KEYCODE: K: 43-617-692 | T: 71-622-460

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567