


Assembly Instructions

K: 43671946 | T: 72034361 REMOVABLE BLOCKOUT WIDE WINDOW FILM



1.
Clean your window thoroughly.
Measure the size of your
window both width & length.



2.
Cut film into proper size,
approximately 1 inch larger
than the window.



3.
Spray water, wet the window
completely.



4.
Peel off the backing clear
protective film gently.



5.
Position the film against the
window and use your finger to
press across the entire top of the
film to allow it to slightly grip.



6.
Smooth out the film with the
squeegee, ensuring there are no
air bubbles. Dry off the window
with the towel.

Installation Tips:

- ◆ The window film is only suitable for indoor, flat, smooth and clean glass. For example, the interior surfaces of windows and glass doors, glass office partitions, and bathroom glass.
- ◆ Remove the transparent backing, and place the smooth side of the film to the window.
- ◆ Spraying a lot of soapy water is the key point, the more water the better.
- ◆ It is recommended that installation be completed by at least 2 people.

Recommended Tools: (not provided with product)

Squeegee,
Measuring Tape,
Stainless Steel Ruler,
Scissors (Razor Knife),
Scraper (Credit Card),
Spray Bottle,
Lint Free Towel.