

BIKE PHONE HOLDER

Keycode:43690664



INSTRUCTION

According to the handlebar Dia. to adjust the rubber pads(D).



1. Attach the handlebar mount clamp(C) onto the handlebar, then joint the mount clamp knob(E) with the mount clamp (C).



2. Slide the mount clamp(C) to a suitable position and tighten it clockwise.



3. Tighten the holder connect knob(F) clockwise to secure.



4. Pull the holder arm and place your phone into the holder(A), adjust phone position and clamp it. Engage the side lock(B) until it "clicks" to secure the phone fixed, to avoid phone drop down during cycling.

WARNING

- 1.Ensure the holder is firmly locked before riding.
- 2.Do not operate your phone while cycling.
- 3.Check the mount regularly for wear or looseness.
- 4.Avoid exposure to extreme heat or prolonged rain.
- 5.Wipe with a damp cloth; do not use harsh chemicals.
- 6.Check the lock mechanism weekly.
- 7.Replace rubber pads if worn.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Phone slips	Arms not tightened	Adjust and lock firmly
Holder rotates loosely	Clamp not tight	Retighten knobs
Lock doesn't engage	Dirt in mechanism	Clean and lubricate