

43507559 OVER THE DOOR JEWELLERY SOLUTION

FITTING INSTRUCTIONS:

- TO AVOID DAMAGE TO PAINTWORK, ENSURE CORRECT FIT & TEST BY CLOSING DOOR GENTLY.
- CAREFULLY UNPACK THE MIRROR FRAME AND LOCATE FITTING INSTRUCTION SHEET, 2 HANGING HOOKS, EVA PADS.
- ADD EVA PADS ONTO THE BACK OF THE FRAME, YOU CAN ADD ANY WHERE THAT YOU WANT TO AVOID THE FRAME TOUCHING THE DOOR DIRECTLY.
- PUT THE HOOK OF THE FRAME INTO THE HOLE ON THE HANGER, THEN PUSH HANGER UPWARDS.
- CAREFULLY HANG THE MIRROR FRAME ON THE TOP EDGE OF YOUR DOOR.

MAX LOAD:

TRAY 1kg, FRONT HOOK EACH 200g.
TOTAL PRODUCT MAX 2kg.

