














Assembly Instructions

CAUTION:

BE SURE YOU HAVE ALL PARTS BEFORE YOU START ASSEMBLING. ASSEMBLE ON A CLEAN SOFT CARPETED SURFACE TO AVOID SCRATCHING THE SURFACE OF THE UNIT. DO NOT KNOCK OR DRAG THE PRODUCT. DO NOT CLIMB UP THIS SHELF UNIT. DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE OF THIS FURNITURE ITEM. WHEN CLEANING THE SURFACE, USE A DAMP CLOTH OR DRY CLEAN CLOTH. DO NOT USE ABRASIVE MATERIALS AND SOLVENTS. KEEP AWAY FROM DIRECT SUNLIGHT. FOR INDOOR USE ONLY. MAXIMUM SAFE LOAD: SHELF (EACH TIER) 6KGS.

WARNING:

THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES UNTIL ASSEMBLY IS COMPLETE. TAKE CARE IF USING POWER TOOLS TO ASSEMBLE THE PRODUCT. IT IS RECOMMENDED YOU CONSULT YOUR TRADE PROFESSIONAL TO ASSIST WITH INSTALLATION OF THE WALL ANCHOR.


	A. Metal Side Frame	2pcs
	B. Shelf	4pcs
	C. Metal Cross Brace	1pcs
	D. Screw M6 x 45mm	16pcs
	E. Hex Key M4X75mm	1pcs
	F. Screw M4 x 30mm	4pcs
	G. Screw Nut	4pcs
	H. Wrench	1pcs
	I. L Bracket	1pcs
	J. Screw M4 x 15mm	1pcs
	K. Screw M4 x 35mm	1pcs
	L. Wall Plug	1pcs
	M. Hex Key M3X75mm	1pcs

①



Tool Required:

Hex Key(M4X75mm)




②



Tool Required:



Hex Key(M4X75mm)



③




Tool Required:
Philips Head Screw Driver
(Not Provided)




Screw to the wall

④



Tool Required:

Hex Key
(M3 x 75mm) & Wrench



⑤

