

# TEE PEE PLAY TENT ASSEMBLY INSTRUCTIONS


---

A. Top pole 4 pcs




A

D. Tee Pee fabric 1pce.



D

B/C. Bottom pole with Plastic connectors 4 pcs



B

C

E. String cord 1pce.



E


PLEASE READ ALL INSTRUCTIONS CAREFULLY. ENSURE YOU HAVE ALL PARTS BEFORE STARTING TO ASSEMBLE THE TEE PEE PLAY TENT.

WARNING: KEEP AWAY FROM ALL FLAME AND HEAT SOURCES.  
NOT INTENDED TO BE USED AS A RECREATIONAL TENT.  
FOR PLAY PURPOSES ONLY.  
ADULT SUPERVISION RECOMMENDED FOR YOUNG CHILDREN.

- 
- 1) Insert the Top Pole (A) into the plastic connectors (B) like below.



- 2) Slide poles into sleeves at each corner of the tee pee, making sure that the holes in top of the poles are at the top of the teepee.



- 3) Thread string through holes in poles as shown. Tie string into a knot to secure poles.

