105x170mm



WARNING: BUTTON CELL BATTERIES CAN CAUSE SERIOUS INJURY OR DEATH IF SWALLOWED. DISPOSE OF SAFELY! STORE BATTERIES OUT OF REACH OF CHILDREN! VISIT THEBATTERYCONTROLLED.COM.AU

	ON/C	0.
(12 + 34)×5÷2=	12+34×5=2=	115.
273 + 572 =	273+572 =	845.
768 + 572 =	768 🗉	1340.
597 - 184 =	597 - 184 =	413.
323 - 184 =	323 🗉	139.
295×8=	295 🖾 8 🗐	2360.
295×6 =	6 🚍	1770.
759+23 =	759 🔂 23 🖃	33.
437 +23 =	437 🔳	19.
5 ² = 5× 5=	5 🛛 🖃	25.
5 ³ =5×5×5=	5 🛛 🖃 😑	125.
1/5=	5 🗄 🗐	0.2
/4 =	4 🗁	2.
75×6/100=	75 🔀 6 🖾	4.5
125/625×100=	125 🗄 625 📆	20.
7.55+(7.55×15%)=	7.55 🛨 15 🖾	8.6825
7.55-(7.55×10%)=	7.55 🚍 10 🚳	6.795
10×20 = ①	ON/C 10 X 20 M+	200.M
-) 5×10 = ②	5 🖂 10 M-	50.M
1-2=3	MR	150.M
	MC	150.
9638527×3 =	9638527 🖂 3 🚍	28915581.
	ON/C	0.
2× <u>3</u> -2× <u>4</u>	2 🖂 3 CE 4 🗉	8.
23.7 TO 1873 (1977)	OFF	

WARNING:

BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY. DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE. CAUTION: BATTERY INSTALLATION BY AN ADULT IS REQUIRED.

REQUIRES: 1 X LR1130 BUTTON CELL BATTERY (INCLUDED) ·SWALLOWING MAY LEAD TO SERIOUS INJURY OR DEATH IN AS LITTLE AS 2 HOURS DUE TO CHEMICAL BURNS AND POTENTIAL PERFORATION OF THE OESOPHAGUS. DISPOSE OF USED BATTERIES AND MAKE SURE THE BATTERY COMPARTMENT IS CORRECTLY SECURED. E.G. THAT THE SCREW OR OTHER MECHANICAL FASTENERS ARE TIGHTENED. DO NOT USE IF THE COMPARTMENT IS NOT SECURE. IF YOU SUSPECT YOUR CHILD HAS SWALLOWED OR INSERTED A BUTTON BATTERY, CALL THE 24HOUR POISONS INFORMATION CENTRE ON 131126 OR IN NZ 0800 764 766 OR CONTACT YOUR COUNTRIES EMERGENCY DEPT.