

Motion Activated LED Headlight with USB Charge



No-Touch Control

Change modes with a wave of your hand

• To Operate Headlamp


1. During use, green indicator LED means full power.
Yellow indicator LED means power is around 30%-70%.
Red indicator LED means power is less than 30%, need to recharge.
2. Lighting mode: Red light- Red light flashing- Spotlight low lighting- Floodlight low lighting- Spotlight high lighting- Spotlight+Floodlight high lighting-Off.
3. In any mode, hold down the switch for 3 seconds to change to sensor function.
Indicator LED in red color. Moving your hand in front of the light, lighting mode will change.
Lighting mode is same as mentioned in point 2.

• To Charge Battery

- Carefully read all instructions before use and save for future reference.
1. Plug small end of USB cord into the headlamp, and the large end into any USB outlet.
 2. A red indicator LED means the battery is charging.
 3. A green indicator LED means the battery is fully charged.
 4. Charging time will take approximately 4-5 hours to fully charge.

• Important Safety Instructions

1. To avoid the risk of electric shock, do not expose the product to water or rain.
2. To reduce the risk of injury, close supervision is necessary when the product is used near children.
3. Only use attachments recommended or sold by the manufacturer.
4. The charging cable is intended for indoor/household use only.
5. Do not use if there is visible damage to light.
6. Do not crush.
7. Do not expose to fire or high temperatures.



Made in China