



# COOL KIDZ KEYBOARD

## INSTRUCTION MANUAL

### Button function description:



1. ON / OFF
2. Volume control
3. Demo songs: press this button to play 10 different songs.
4. Special sounds effect: press these buttons to play the special sounds on the keys.
5. Stop / Play
6. Record: press this button to record the 20 notes you played, then press the Play button to play the recorded music.
7. Drum sounds
8. Tempo control: control the tempo of demo songs.
9. Dance rhythms
10. Instrument selections: press these 5 buttons to make their related sound by pressing the keyboard.



**WARNING:** BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY. DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

keycode: 42742241

ADULT SUPERVISION REQUIRED.  
PRODUCT MAY VARY FROM THE IMAGE SHOWN.  
PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.

**CAUTION:** BATTERY INSTALLATION BY AN ADULT IS REQUIRED.

**WARNING: CHOKING HAZARD**  
SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.