

# Assembly Instructions












## 42839729 NOIR STORAGE UNIT











**CARE INSTRUCTIONS:** WIPE CLEAN WITH A DRY CLOTH. DO NOT USE ABRASIVE MATERIALS AND SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR DOMESTIC USE ONLY. FOR INDOOR USE ONLY. A MILD ODOUR MAY BE PRESENT WHEN FIRST OPENING THIS CARTON. SIMPLY ALLOW TO AIR OUTSIDE AND THIS WILL FADE.

**WARNING:** DO NOT STAND OR SIT ON THIS UNIT. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED. DO NOT KNOCK OR DRAG THIS UNIT. USE ONLY ON A FLAT SURFACE. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY. LOAD DRAWER EVENLY TO PREVENT FROM TIPPING OVER. THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES. **MAXIMUM SAFE LOAD: 15KGS FOR TOP PANEL , 10KGS FOR MIDDLE SHELF , 5KGS FOR BOTTOM PER SHELF .**
















1

### Hardware List


	a	6x35mm	10pcs
	b	15x9.5mm	10pcs
	c	6x30mm	22pcs
	d	4x35mm	11pcs
	e	iron skeleton	1 pc
	f	3x14mm	4pcs
	g	2x16mm	22pcs
	h	4x25mm	8pcs
	i	6x25mm	6pcs
	j	hinge	2pcs
	k	4x14mm	12pcs

	l	4x18mm	2 pcs
	m	handle	1 pc
	n	4x12mm	2 pcs
	o	6x50mm	2 pcs
	p	nail	3 pcs
	q	wall fixing	4 pcs
	r		2 pcs
	s		2 pcs
	t		2 pcs
	u	hex key	1 pc

2


		
① 1PC	② 1PC	③ 1PC
		
④ 1PC	⑤ 1PC	⑥ 1PC
		
⑦ 1PC	⑧ 1PC	⑨ ⑩ 2PCS
		
⑪ 1PC	⑫ 2PCS	⑬ 2PCS
		
⑭ 1PC	⑮ 1PC	⑯ 2PCS

3




### Step 1:

Attach part e onto board 1 with part f (as per below diagram)  
Attach board 7 onto board 1 with part c&d (as per below diagram)




### Step 2:

Attach part 14 onto board 2 with part l (as per below diagram).  
Fix the screws part a&b onto board 1&2 and put part c into the corresponding position (as per below diagram).  
Attach board 4&5 to board 1&2, and then fix the round screws part b with a screwdriver.  
Ensure all parts align.



### Step3:

Fix the screws part a&b onto board 6 and put part c into the corresponding position (as per below diagram).  
Attach board 6 onto board 2, and then fix the round screws part b with a screwdriver. Ensure all parts align.  
Attach board 3 onto board 4&6&5 from previous step with screws part d.




### Step 4:

Attach board 9 onto the back with part g by a hammer and use a screwdriver to attach part 12 onto board 3 with screws part h, then attach part 11 onto part 12 with part i by a hex key part u.


After that, use a hex key part u to attach part 11 onto part 12 and attach part 13 onto part 11 with part i.

Make sure to be on a corresponding position (as per below diagram and all parts align). At last, attach wall fixing part t&q&r onto board 7 with a corresponding position. (as per below diagram).



### Step 5:


Attach board 15 onto board 8 with part o (as per below diagram)  
Attach handle m onto board 10 with screw part n (as per below diagram)



### Step 6:


Use a screwdriver, attach hinge part j onto board 10 with screw part k first then attach onto board 5.

Notes: Make sure this screws are tightened with a screwdriver (as per below diagram)



### Step 7:

Put shap X boards from step 5 into the space beside the door.



### Step 8:


At last, attach the wall fixings onto the wall with part s&q&d.

#### Warning:

It is strongly recommended that this product is permanently fixed to the wall.

- › Please seek professional advice if you are in doubt of what fixing device to use.
- › Regularly check that anchors are securely maintained
- › Use safety drawer locks to prevent children climbing
- › Stability of tall items may be affected by thick pile carpet or uneven floors
- › Do not place unanchored televisions on furniture (If applicable)

**Caution:** for your safety when attaching the anchor fixings, please note the following:  
Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson)



**ATTENTION:**  
DO NOT TIGHTEN THE SCREWS FULLY DURING ASSEMBLY.  
FULLY TIGHTEN SCREWS AFTER THE FINAL ASSEMBLY STEP.

