

Cleaning:

Wash, rinse and dry the plunger before using it for the first time. The plunger is dishwasher safe however do not use steel wool or abrasives to clean the glass jug as this may scratch the glass. The mesh filter needs to be handled carefully as the edges can be flipped up and either begin fraying or give an unexpected cut.

How to use the plunger:

Remove the lid and plunger and fill the glass jug with hot water to preheat it. Empty water then add the desired amount of coffee to the plunger and add hot water (not boiling) as boiling water can burn the ground coffee causing a bitter taste. With the plunger pulled all the way to the top, put the lid back on and let the coffee brew. Push the plunger down carefully to separate the coffee grounds from the brew. Now you are ready to pour and serve.

IMPORTANT!

The plunger should not be exposed to variations in temperature, as the glass could crack. Never pour hot water into a plunger that is taken directly from a fridge or freezer.