

anko

Instruction Manual

Keycode: 42895831




*Please read all the information carefully before you use the product and keep the manual for future reference.

1. Specification:

- Sensing module 90 degrees rotation
- 4white LED light
- 3*AAA battery (not included)

2. Structure Description:

- Sensing module 90 degrees rotation
- 4white LED light
- 3*AAA battery (not included)




3. Installation Description:

- (1) Stick the plastic clips with 3M glue to the cupboard or closet.
(Note: the lamp bar is placed on the right side of the entrance)
- (2) Then push the lamp into the plastic buckle as the direction shown in the above picture.


4. Direction For Use

- (1) Place the battery correctly and close the battery cover,
- (2) Set the switch to "AUTO", the LED light goes into motion detect mode. When in a dark area, once a person or animal enters the sensing area, the light will turn on for 30 seconds.
- (3) Set the switch to "ON" for Always on mode
- (4) Set the switch to "OFF" when not in use.



5. Detection distance

- Within 3meters and 100°



6. Attentions

- This product should be used indoors, please do not use it in direct sunlight, rains, or heavy moisture.
- The sensor will not work beyond its sensing range
- Battery life is a rough figure, it will be different depending on the frequency and time of use, battery life from different brands will also be different.
- Please check for battery regularly. Remove the battery when not for use in a long period.
- Old and new battery should not use at the same time.
- Difference type of battery should not mixed.