

anko

Instruction Manual

Mini Mechanical Gaming Keyboard

Keycode: 43099771



Safety Instructions:

Please read the instruction manual before using this device and follow all the safety instruction to avoid damage caused by improper use.

- Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- Use this device solely for its intended purpose.
- Only use this appliance indoors.
- Keep the appliance away from all hot surfaces and naked flames.
- Always put the appliance on a level, stable, clean, dry surface. Protect the appliance from extreme heat and cold, dust, direct sunlight, humidity and drops or jets of water.
- Do not immerse the appliance in water or in other liquids.
- Do not open the housing under any circumstances.
- Do not introduce any objects into the interior of the housing.
- Should the device malfunction due to electrostatic discharge or a short power surge, disconnect it from your computer and then reconnect it again.

Features:

- * Ultra-compact mechanical mini keyboard
- * 21 keys anti-ghosting
- * 61 mechanical keys
- * 12 kinds of lighting effects
- * Working Voltage: 5V, 100mA
- * Dimension: 290*100*39mm

Supports

Windows 7/8/10

Key function

Combination key	FUNCTION	Remarks
FN+ESC	·	
FN+ESC+ Shift	~	
FN+1	F1 function	
FN+2	F2 function	
FN+3	F3 function	
FN+4	F4 function	
FN+5	F5 function	
FN+6	F6 function	
FN+7	F7 function	
FN+8	F8 function	
FN+9	F9 function	
FN+10	F10 function	
FN+ -	F11 function	
FN+ =	F12 function	
FN+,<	Page Down	
FN+W	Separately press the key of "A S D W" to switch into the function of ←↓→↑	
FN+WIN	lock WIN	
FN+] }	LED brightness +	Brightness adjust, 3 brightness levels, default level3
FN+ [{	LED brightness -	Brightness adjust, 3 brightness levels, default level3
FN+ ' "	LED speed +	LED running speed adjust, 2 different speeds
FN+ ; :	LED speed -	LED running speed adjust, 2 different speeds
LED 	switch LED mode	in total 12 modes
FN+CTRL(The left one)	Switch first line key function	Separately press the key of " Y U I H J K N M , < " to switch to the function of "Print Screen /Scroll Lock/ Pause/ Insert /Home/ Page Up/ Delete/ End/ Page Down"
FN+ space key	reset	long press for 3 seconds to reset this keyboard

How to use:

Plug and Play, USB plug into PC, it can be used.

Care and maintenance

Wipe all parts with a dry soft cloth.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at [Kmart.com.au](https://www.kmart.com.au) for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.