

120\*150mm 105双铜双面印

anko

18" Selfie Ring Light with Stand  
Keycode: 43157099  
Instruction manual



- IMPORTANT SAFETY INSTRUCTIONS:**  
The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury or fire. It is important to read all of these instructions carefully before using the product, and to save them for future reference or new users.
- This product must only be used as intended in accordance with the enclosed operating instructions.
  - Do not carry the appliance by the mains cable or pull the cable to remove the plug from the socket.
  - If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
  - If the luminaire stops unexpectedly or appears to malfunction, switch off the power supply, unplug from the mains and stop using immediately. Seek professional advice to rectify the fault or make repairs.
  - Switch off the power supply or unplug from the mains socket when not in use, before cleaning or changing accessories.
  - Avoid positioning the luminaire where the power cable might be accidentally trapped or damaged.
  - Keep the luminaire and cable away from sources of heat, sharp objects or anything that may cause damage.
  - Ensure the luminaire is switched OFF before connecting the mains power supply.
  - Be aware that some surfaces may become hot. Do not touch hot surfaces and supervise others accordingly.
  - This product has not been designed for use by children.
  - Children should be closely supervised at all times when they are near any electrical appliance.
  - To protect against electric shock, never allow the luminaire, the mains cable or plug to come into contact with water or any other liquid.
  - Never reach for any appliance that has fallen into water. Switch off the power supply at the mains immediately and unplug. Do not re-use until the product has been inspected and approved by a qualified electrician.
  - Always ensure that hands are dry before operating or adjusting any switch on the product or touching the plug and mains supply connections.
  - To disconnect, first ensure that all controls are in the OFF position, then remove the plug from the electricity supply.
  - Do not use outdoors. This luminaire has been designed for domestic indoor use only.
  - Use only a microfiber and dry cloth for cleaning the product.
  - Operate carefully to not cause any damage by dropping or physical shocking it.
  - Do not leave the product in excessive heat, high temperatures can

- cause the product to malfunction.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- For indoor use only.
- Use provided AC adaptor with power cable and plug only.

**Packing list:**  
Ring light x1, Adjustable stand x1, Bluetooth remote control x1, Bagx1  
AC Adaptor x1  
AC adaptor: BCM-1540  
Input: 220-240V~50/60Hz, 1.6AMax;  
Output: 15V d.c. 60W

**User Manual and installation for the LED Driver (AC Adaptor):**

1. Before connecting the DC plug to the luminaire, make sure LED Driver (AC Adaptor) is plug off from mains and determine whether the voltage and current rating match the input of the luminaire.
2. Put the power connector (power cord) to LED Driver (AC adaptor) firmly and plug in the power plug to mains. \*Ensure all connection is fixed firmly before plug into mains\*.
3. The power cord must be placed in an environment that will not be trampled or squeezed.
4. To avoid overheating, install the LED driver (AC adaptor) in a well-ventilated environment. If the adjacent luminaire primary heat source, it must be 10 cm minimum from the luminaire.
5. If the luminaire is not in use for a long time, remove the LED driver (AC Adaptor) to prevent the luminaire from be in damaged by inductive lightning strike or voltage surge.
6. See below for installation in recessed mounted.  
The LED Driver (AC adaptor) is classified as "Do-not-cover". See note and diagram as below.  
(a) The minimum clearance distance from the top and sides of the LED driver (AC Adaptor) to normal flammable building elements is 100mm.  
(b) The LED driver (AC Adaptor) is not required to be mounted on a specific surface and has no additional installation requirements.




Diagram shows the mounting requirement  
(C) For indoor use only.

**How to use:**  
1. Adjust the height by pulling out the middle pole. Suggest to use this product when the stand is opened to 90°.



2. Attach the light to the stand, rotate the joint to fix the light to the stand.



3. Adjust a suitable lighting angle, screw the knob to fix it.




4. Screw the phone holder to the ring light, you can put your phone on the phone clip.




5. Use the included adapter connect to the ring light and socket.

**Product Overview:**  
1. Ring light




- A. ON/OFF Key  
B. Brightness decrease. Press once to reduce brightness.  
C. Brightness increase. Press once to increase brightness.  
D. Color temperature adjust. Short press to change the color temperature.



1. Mobile phone clamp fixing slot
2. Power Input socket
3. Angle adjustment knob
4. Bracket fixed knob
5. USB charging port

**Bluetooth selfie remote control.**



**Warning: Batteries installation by an adult is required**  
Please install 2 x1.5V AAA batteries (batteries not included) before start to use Bluetooth selfie remote control.  
• After install 2 x1.5V AAA batteries, remote control is ready to pair with your mobile phone.  
• In the Bluetooth menu on your mobile phone, search for "BT2022" and connect.  
• Remote control is ready to use now.  
• Press button to take selfie/photo.  
Note: Remote control will enter sleep mode after several minutes. Press button to re-activate the remote.