


297x210mm


FRONT

Assembly Instructions


43224777 Multi tier laundry hamper




A: 1PC




B: 1PC



C: 1PC




D: 2PC



E: 2PC




F: 2PC



G: 4PC




H: 2PC




I: 2PC

BACK


Step 1




Step 2




Step 3




Step 4



Step 5



Step 6



Step 7

