

15x11cm

### **Microwave Cleaner – Safe Use Instructions**

1. Remove the cap from the microwave cleaner.
2. Fill the body with equal amount of water and vinegar (eg. 100ml vinegar + 100ml water).
3. Secure the cap tightly back onto the cleaner.
4. Place the cleaner upright in the center of your microwave.
5. Microwave for 5–7 minutes.
6. Wait for 2 minutes after heating before opening the microwave to allow steam to settle.
7. Carefully remove the cleaner (it will be hot!) and wipe down the interior of the microwave with a clean cloth.

#### **Important:**

- › Do not overfill the cleaner to prevent spillage.
- › Handle with care after heating; the cleaner and liquid inside will be extremely hot.
- › Do not use harsh chemicals inside the cleaner – only water and natural solutions like vinegar or lemon juice.
- › Keep out of reach of children during and after use.
- › Do not exceed recommended time to avoid damage or overheating.