



Use + Care Instructions:

1. Rinse thoroughly before first use.
2. For optimal performance, clean the bottle after multiple uses with a mild vinegar solution or soap and water.

For any leaks or drips from spout assembly:

1. Ensure both gaskets are correctly oriented on the spout assembly. Both gaskets should have the round side facing the bottle wall as illustrated in the graphic above.
2. Further tighten the nut on the inside of the bottle. Note: overtightening the nut may cause the bottle to crack, make small adjustments until the leak stops.

Expanded view of parts supplied

Caution:

- Keep out of reach of children.
- Breakable, handle with care.
- Do not move when full.
- Not recommended for hot liquids or carbonated drinks.
- Ensure the spout has been tightened as per the instructions below prior to using.
- To allow a consistent flow of liquid from the dispenser, do not fully tighten the lid.