

# Instruction Manual


## Collapsible Pop Up Laundry Airer

K:43-536-504 | T:70-933-222

**CARE INSTRUCTION:** WIPE CLEAN WITH A SOFT DRY OR DAMP CLOTH. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. FOR INDOOR AND DOMESTIC USE. CHECK AND TIGHTEN ALL PARTS REGULARLY.

**WARNING:** DO NOT STAND ON THE UNIT. DO NOT LEAN ON THE PRODUCT. DO NOT USE UNTIL ALL SCREWS, BOLTS AND KNOBS ARE FIRMLY SECURED. THIS PRODUCT CONTAINS SMALL PARTS AND SHARP POINTS, KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


**MAXIMUM LOADING WEIGHT OF:** EACH ROD:1KG; EACH CLIP:0.1KG,18KGS IN TOTAL.



Tips: Please wear gloves when using.


## Open steps

### STEP 1




Caution:  
Press the button with your foot,  
hold the cylinder with both hands,  
and lift upwards.

### STEP 2




### STEP 3



Caution :  
Hold the position as shown with  
your hands.


Open the 4 legs fully before use.

### STEP 4





Caution :  
Pull the cylinder upwards,until you hear  
a “click” sound.

## STEP 5




## STEP 6






## Storage steps


### STEP 1



### STEP 2




### STEP 3



**Caution:**  
One hand hold the button, while the other grabs the cylinder and put it slowly down to finish the storage.


**Warning:** please hold down or let go of button and to keep fingers away.

### STEP 4



**Caution:**  
Hold the cylinder with your both hands and close the legs with your foot.

## STEP 5



Caution:  
Hold the position as shown  
with both hands.

## STEP 6

press to fix ↓

