









Assembly Instructions








43541003 MORGAN BEDSIDE TABLE-2 DRAWER













WARNING: DO NOT STAND, SIT OR LEAN ON THIS UNIT. DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE. KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. USE ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.


CARE INSTRUCTIONS: TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE. WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR AND DOMESTIC USE O

MAXIMUM SAFE LOAD: 10KG FOR TOP PANEL, 5KG FOR EACH DRAWER.

	a	M6x35	14pcs
	b	M15x10	14pcs
	c	M3x12	28pcs
	d	M6x30	10pcs
	e	M4x35	12pcs
	f	M4x12	16pcs
	g		2pcs
	o		4pcs


	h	M3x14	4pcs
	i		4pcs
	j		2pcs
	k		2pcs
	l		2pcs
	m		2pcs
	n		1pc

			
① 1pc	② 1pc	③ 1pc	④ 1pc
			
⑤ 1pc	⑥ 2pcs	⑦ 2pcs	⑧ 2pcs
			
⑨ 2pcs	⑩ 2pcs	⑪ 4pcs	⑫ 1pc




step 1

 a x 2  c x 16  j x 2  k x 2




step 2

 b x 2  d x 2




step 3

 a x 4




step 4

 b x 4  d x 4




step 5




step 6

e x 4 d x 4




step 7

f x 16



step 8


e x 8 a x 8 g x 2 o x 4



x2

step 9


b x 8



x2



step 10


c x 12 m x 2 l x 2




x2

step 11


 h x 4  i x 4




step 12



step 13

 n x 1



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.




TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).

! WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.
- Furniture type is at risk of toppling over.

NEVER put a TV on this furniture



This is a permanent label. Do not remove!