Assembly Instructions

43541119 CHARLES CHEST OF DRAWERS

WARNING: DO NOT STAND, SIT OR LEAN ON THIS UNIT. DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE. KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. USE ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.


CARE INSTRUCTIONS: TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE. WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR AND DOMESTIC USE ONLY.


MAXIMUM SAFE LOAD: 15KG FOR TOP PANEL, 7KG FOR EACH DRAWER.


1) Hardware List				
©		Α	M6x35mm	29pcs
	8	В	Ø15x9mm	29pcs
		C	Ø6x30mm	23pcs
•		D	M4x35mm	24pcs
(\bigcirc	Ε		4pcs
		F		8pcs
	•	G	M3x16mm	8pcs
0		Н		2pcs
	0	1		2pcs
		J	M3x12mm	42pcs
<u> </u>	• • _ • • • • • • • • •	CL		3pcs
5000 B 0	• • • • • •	CR		3pcs
9*	'	DL		3pcs


3pcs


Hardwara List


















STEP 15:













STEP 20:



STEP 21:



TOPPLING FURNITURE WARNING:

- ALWAYS secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors.
- Do not place unanchored televisions on furniture.

CAUTION: for your safety when attaching the anchor fixings, please note the following:

 Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.



A WARNING





Children have died from furniture tipover.

- · ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This is a permanent label. Do not remove!