

## Cleaning & Maintenance:

- 1) Turn the light Bar off before you start cleaning it.
- 2) Do not immerse the appliance in water. Clean the light Bar surface with a dry cloth .
- 3) Do not use any lubricant, detergent, polishing agents, alcohol, steel wool, abrasive cleansers, chemicals or corrosive liquids on this light Bar.

## Battery and light bar disposal:

1. This light bar has a lithium battery. Batteries contain substances harmful to our environment, please do not dispose of the light bar containing batteries with the normal household waste, instead hand it over to an official recycling point.

## 2.Trouble Shooting

Problem	Possible Cause	Solution
LED Light is not bright enough or it does not turn on	The battery is running low or is out of power	Charge the light bar as guided

## Packing Incuded:

- 1 pcs motion sensor light
- 2 pcs plastics pad
- Type-C USB charging cable
- User Manual


# anko

## 40CM MOTION SENSOR LED LIGHT BAR

K: 43543212 | T: 70963472

SLR-24234

## INSTRUCTION MANUAL



## Product Description:

- |                          |                    |
|--------------------------|--------------------|
| ① LED Lamp               | ⑤ Function button  |
| ② Infrared motion sensor | ⑥ Plastics pad     |
| ③ Charging port          | ⑦ Type-C USB cable |
| ④ On/Off button          |                    |

## Safety Instructions:

To ensure proper operation of this light bar, please read this instruction manual carefully before you use the light bar and save it for further reference.

### ⚠ WARNING

- Check the light bar before you use it, do not use the light bar if it has any crack, gap or any other damage.
- Do not attempt to repair, disassemble, or modify the light bar by yourself to avoid accidents.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- Do not stare into the LED beam.
- This product is not suitable for household room illumination. Only used as decorative light.
- The product is intended to be used in moderate climates only. Do not use in tropical or very humid climates.
- Children must not use this product without adult supervision.
- Do not charge the product for long time. Plug off the charging cable after fully charged

### ⚠ CAUTION

- This light bar has a lithium battery. Do not place or store the light bar for long periods of time in a hot or humid environment. If you do not intend to use the light bar for a long time, store the light bar after is fully charged.
- Do not use while charging. (The charging indicator light is on during charging, which interferes with infrared motion sensor and cannot work properly)
- This light bar contains battery and LED lights that are non-replaceable.
- Ensure charging power used is compatible with a 5V DC SELV 1A, 5W rating.

## Specifications:

- Charging Voltage / Current: 5V  $\overline{\text{---}}$  / 1000mA Max. 5W
- Type of Battery: Li-polymer 3.7V 650mAh
- Ta: 25°C

## Assembly Instructions:

- 1) Before adhering strip lights, clean the surface of the area you will be placing the lights on, and keep it smooth & dry. It is recommended to apply your strip lights on smooth stable surfaces. It should not be placed on rough, textured or painted wall surfaces or any surfaces that can bend or move.
- 2) Remove the protective film of the plastics pad. Stick on the plastics pad to cabinet surface, press it to make sure it firmly stick. You can detach LED light bar when recharging.
- 3) Only charge the lamp with the supplied USB cable.

## Using the Appliance:

For better use experience, please read below instructions carefully:

1. This appliance needs to be charged if the light ray is not bright enough. Please use 5V DC SELV 1A 5W adaptor(not included) to charge.
2. The charging indicator light will be red while charging. After being fully charged, it will turn green.
3. There are two buttons on the side of the product: on/ off button and function button.  
On/Off button: press 1st time to activate the constant light mode. The light will be always lighting in this mode.  
Press 2nd time, the light flashes three times to start the night motion sensor mode. The sensor only can detect the movement when the environment in low light ray.  
Press 3rd time, the light flashes two times to start the routine motion sensor mode. The sensor can detect the movement always and will be lighted, whatever in day or night.  
Press 4th time to turn off the light.  
Function button: short press to adjust the colour temperature. There are three colours on this product: daylight, cool & warm light. Long press the adjust the light brightness.  
Auto-triggered by infrared motion sensor when detected movement.