## Assembly Instructions K: 43544035 | T: 70965643 ISLA 3 TIER CADDY


## CARE INSTRUCTIONS:


Wipe clean with a dry cloth. Never use scourers, abrasives or chemical solvents, keep away from moisture and direct sunlight. Store in a dry place, for indoor use only. **WARNING:** 


Do not stand, sit, or lean on the unit. Ensure this unit is used only on a flat surface. Do not use this unit unless all bolts and screws are firmly secured. Do not place hot objects, such as coffee cups, directly on the surface of this furniture item. This item is for storage purposes only. Contains small parts. It is to be assembled by an adult. Failure to follow these warnings could result in serious injury.


2 Hardware List 1 Ĵ В 1pc 6x35mm 10pcs Α 3mm ۲. 15x10mm 10pcs D 24pcs С 5x38mm (1)2pcs (2) (3) 1pc 1pc 4x35mm F Е 12pcs 6x30mm 2pcs G 2pcs 0 ο 1pc (5) 1pc (6)3pcs (4)3 2 (8) (7)1pc 1pc (9)1pc (10) (11) (12) 1pc 1pc 1pc (14) (13) (14) 1pc 1pc

MAXIMUM SAFE LOAD: 5kg for each shelf.









WALL

G



## TOPPLING FURNITURE WARNING:

- ALWAYS secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture.

**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

• Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).

