

Assembly Instructions








K: 43-548-194 | T: 70-979-862 LAUNDRY HAMPER SET

CARE INSTRUCTIONS: Check and tighten all parts regularly. Wipe clean with a soft damp cloth. For indoor and domestic use.


WARNING: Do not stand, sit or lean on the hamper. Use only on a flat surface. This package contains small parts, keep away from children and babies. Adult assembly required. Failure to follow these warnings could result in serious injury.

MAXIMUM SAFE LOAD: 10kg

Hardware list

	A	1PCS		B	1PCS		C	1PCS
	D	2PCS		E	2PCS		F	2PCS
							G	2PCS


STEP 1



X1

A

STEP 2




X1

B

A


STEP 3



X1


C

STEP 4



X2

X2




F

G

G


F

STEP 5




D


D



X2



X2




E


D

STEP 6

Option 1



Option 2



Open

Option 3

