
anko

Panel Playpen Instruction Manual



297mm



The photos and illustrations shown in this instruction manual are generic. The manufacturer reserves the right to change any specification or feature without prior notice.


IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.

PANEL PLAYPEN


Attention:

- 1. Adult only assembly is required. Ensure to carefully follow the assembly instructions.
- 2. Ensure the nuts, hinge connectors, and non-slip connectors are secured after assembly and prior to use.
- 3. Ensure the playpen is used on a flat level ground.
- 4. Adult supervision is required. This playpen is not intended to replace adult supervision. Never leave child unattended. Do not allow child to climb the playpen.
- 5. Check that the playpen is in good condition before each use. Do not continue to use if it is damaged or upside down.
- 6. This playpen can be assembled in adaptable shapes.


Parts List:




Activity Play Panel x 1 piece



Panel x 12 pieces




Door panel x 1 piece



Non-Slip Connector x 14 pieces





Nut x 28 pieces



Hinge Connector x 14 pieces

Assembly Instructions:





After assembly is completed, ensure that all connections are securely fixed before use.

CARE INSTRUCTIONS:

SURFACE CLEAN ONLY.
WIPE CLEAN WITH A DAMP CLOTH.
DRY WITH A SOFT ABSORBENT CLOTH.

K: 43-549-474 T: 70-985-184

MADE IN CHINA

RETAILER INFORMATION IF SOLD BY:

KMART AU: 690 SPRINGVALE RD, MULGRAVE VIC 3170 AUSTRALIA.

KMART NZ: REGIONAL OFFICE C/O KMART PAPATOETOE STORE, HUNTERS PLAZA, GREAT SOUTH ROAD, PAPATOETOE, AUCKLAND, NEW ZEALAND.

TARGET AU: 2 KENDALL ST, WILLIAMS LANDING VIC 3027 AUSTRALIA.

CUSTOMER SERVICE:

KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567

