

DUCK GALLERY




STICKER





INSTALLING BATTERIES

- 1 Open the battery compartment.
- 2 Insert 3 x 1.5V AA batteries with the correct + and polarities.
- 3 Close the cover.




CONTENTS:


1 X Duck gallery stage, 6 Ducks, 1 X Blaster, 12 X Darts, 1 X Sticker sheet

SET UP:

Turn the power switch to the ON position, then press the reloading button. The continuous belt will start moving. Install the ducks on the belt in the order of 5 - 10 - 20 - 5 - 10 - 20.








HOW TO PLAY

Press the Start button. The 3 - second countdown ends, and the game starts. Players have 1 minute to knock down as many ducks as possible.




Game Distance

The recommended distance between the Duck Gallery and the blaster is 3 - 3.5 metres. Players can also agree on a suitable distance before starting the game.

How To Win

The player with the highest score wins the game.

After playing, store ducks in the back panel box.



WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.



WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: THIS TOY CONTAINS MAGNET COMPONENTS. MAGNETS STICKING TOGETHER OR BECOMING ATTACHED TO A METALLIC OBJECT INSIDE THE HUMAN BODY CAN CAUSE SERIOUS OR FATAL IN INJURY. SEEK IMMEDIATE MEDICAL HELP IF MAGNETS ARE SWALLOWED OR INHALED.

MARNING: CHOKING HAZARD
SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: DO NOT AIM AT EYES OR FACE. DO NOT USE PROJECTILES OTHER THAN THOSE SUPPLIED BY MANUFACTURER.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

ADULT ASSEMBLY REQUIRED.
PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN.
PLEASE KEEP PACKAGING FOR FUTURE REFERENCE.