Assembly Instructions PET CRATE WOOD WHITE MEDIUM

CARE INSTRUCTION: Wipe clean with a soft dry or damp cloth. Keep away from water and direct sunlight. For indoor and domestic use. Check and tighten all parts regularly.
WARNINGS: Do not stand or sit on the unit. Do not lean on the product. Do not drag the product. Use only on a flat surface. Do not use until all screws, bolts and knobs are firmly secured. Load the drawer evenly to prevent it from tipping over. This product contains small parts and sharp points, keep away from children and babies. Adult assembly required. Failure to follow these warnings could result in serious injury.

MAXIMUM TOTAL LOADING WEIGHT: TOP PANEL:15kg (MAXIMUM), BOTTOM PANEL:20kg (MAXIMUM).

	Hardware				
on Et	а		11PCS		Ć
No.	b		11PCS		(B)
	С	6X30mm	22PCS		
(a) Jananananan	d	5X40mm	17PCS		
(S) IIIIII	е	3X12mm	10PCS		ſ
anne -	f		2PCS		V
(A) JULION	g	3.5X12mm	4PCS		
	h		1PC		
	i		1PC		¢
		•			

ware list									
0	j		1PC						
Bunning	k	3X14mm	6PCS						
	ι		1PC						
	m		4PCS						
	n		1PC						
8) ^{mm}	0	4X12mm	1PC						
	р		1PC						
8 Januar	q	4X35mm	1PC						
Constant	r		1PC						
		j k l m n n o p p	j k 3X14mm k 3X14mm k 3X14mm k 1 k k 3X14mm k 1 k 1 k 1 k 1 k 1 k 1 k 1 k 1 k 1 k 1						



DO NOT TIGHTEN THE SCREWS UNTIL THE PRODUCT IS FULLY ASSEMBLED.













STEP 18 🖋 x1 🍆 x1 🍾 x1 💞 x1

Warning:

• It is strongly recommended that this product is permanently fixed to the wall.

• Please seek professional advice if you are in doubt of what fixing device to use.

• Regularly check that anchors are securely maintained.

Use safety drawer locks to prevent children climbing.

Stability of tall items may be affected by thick pile carpet or uneven floors.

• Do not place unanchored televisions on furniture.

Caution: for your safety when attaching the anchor fixings, please note the following:

• Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson)





Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture

This is a permanent label. Do not remove!







Guide to Crate Training your dog.

Crate training can have real benefits in providing a safe haven for your dog, it does take time and can require patience. Crates can be ideal for transport, for sleeping and even training for the stay at the Vets. Crate training is not right for all dogs and dogs should not be left alone for prolonged periods of time. Crate training should not be used for dogs who are claustrophobic, have anxiety or are anxious. Crates should not be used as a form of punishment. If your dog barks or whines while in the crate, don't shout or bang the crate, this may cause fear. The dog may want to toilet or just want to be let out. Not all dogs like to be in a crate.

Make sure that the crate size you select is the right size for your dog, it should be big enough for the dog to stand and turn around. Remember "bigger is not always better" since being too roomy, it isn't snug and may not feel safe. Look at the guide on the packaging to make sure.

The pet crate needs to be a place where your dog feels comfortable, where it can sleep and be secure. Make sure that the bedding is clean and comfortable, add favorite toys. Always use positive rewards, place treats within the crate.

Begin by feeding your dog in the crate and encouraging the dog to enter. Encourage your dog to spend longer in the crate, always stay close and supervise during this training phase. Once your dog has spent 30 minutes in the crate calmly, you can leave them for longer periods of time eg a couple of hours. If your dog sleeps in the crate, it will let you know when it needs to toilet, take it out and reward the dog just before return to the crate.

It is not acceptable to leave dogs in crates for long periods of time eg while you are at work. Adult dogs should not be left for more than 3-4 hours in a crate, puppies not more than 1-2 hours. If you are going to leave the dog for extended periods of time, place the crate with the door open into an enclosed area such as a bathroom and remove any possible hazards. Always ensure that there is a clean supply of water.

If your dog shows any signs of distress such as biting the crate etc, let the dog out. If the dog continues to be distressed through training, the crate is not the right choice for your dog.