

Assembly Instructions














K:43553884 | T:71221007 / RYAN BEDSIDE TABLE

WARNING: DO NOT STAND, SIT OR LEAN ON THIS UNIT. DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE. KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. USE ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.



















CARE INSTRUCTIONS: TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE. WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR AND DOMESTIC USE ONLY.

MAXIMUM SAFE LOAD: TOP:10KG; DRAWER: 5KG.


1 Hardware List

	A		14pcs		B		14pcs		C	Ø6x30mm	10pcs
	D	M4x12mm	33pcs		E	M4x35mm	13pcs		F	M4x30mm	4pcs
	G	M7x50mm	4pcs		H	Ø30mm	4pcs		I		4pcs
	J	Ø8x30mm	4pcs		K		1pc		L		1pc
	M	M4mm	1pc								

2 Parts List








							
①	1pc	②	1pc	③	1pc	④	1pc
							
⑤	1pc	⑥	1pc	⑦	2pcs	⑧	2pcs
							
⑨	2pcs	⑩	2pcs	⑪	1pc	⑫	1pc
							
⑬	2pcs	⑭	2pcs	⑮	2pcs	⑯	2pcs
							
⑰	2pcs	⑱	4pcs				

3





ATTENTION:
DO NOT TIGHTEN THE SCREWS FULLY
DURING ASSEMBLY. FULLY TIGHTEN
SCREWS AFTER THE FINAL ASSEMBLY
STEP.

STEP 1 A - x 8 B - x 8 D - x 12 E - x 8 F - x 4




Tool required
Phillips Head Screw Driver
(Not Provided)




X2

STEP 2 D - x 16




Tool required
Philips Head Screw Driver
(Not Provided)

STEP 3 A - x 2 B - x 2 C - x 2




Tool required
Philips Head Screw Driver
(Not Provided)

STEP 4 G - x 4 H - x 4 J - x 4




STEP 5 A - x 4 B - x 4 C - x 4




Tool required
Philips Head Screw Driver
(Not Provided)

STEP 6 C - x 4 E - x 4





Tool required
Philips Head Screw Driver
(Not Provided)

STEP 7




STEP 8

D - x 4 I - x 4




STEP 9

D - x 1 E - x 1 K - x 1 L - x 1



WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.
- Furniture type is at risk of toppling over.

NEVER put a TV
on this furniture




This is a permanent label. Do not remove!

TOPPLING FURNITURE WARNING:

- ALWAYS secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE
YOUR FURNITURE WITH
THE SUPPLIED WALL FIXING.
SCAN THE CODE FOR
MORE INFORMATION.

