# **Assembly Instructions**

### 43553891 RYAN CHEST OF DRAWERS

**WARNING:** DO NOT STAND, SIT OR LEAN ON THIS UNIT. DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE.KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. USE ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.


**CARE INSTRUCTIONS:** TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE. WIPE CLEAN WITH A SOFT DAMP CLOTH.NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR AND DOMESTIC USE ONLY.


MAXIMUM SAFE LOAD: TOP:15KG; DRAWER:7KG.


### 1 Hardware List


	А		32pcs		В		32pcs	077777J)	С	Ø6x30mm	20pcs
<b>()</b>	D	M4x12mm	66pcs	<b>(</b> ):::::::::→	Е	M4x35mm	30pcs	0)1	F	M7x50mm	4 pcs
	G	M8x30mm	4 pcs	()::::::::>	Н	M4x30mm	8pcs	8	I		8pcs
	J	Ø30mm	4 pcs	The state of the s	K		2pcs	0 0	L		2pcs
	M	M4mm	1рс								


## 2 Parts List



















Tool required
Philips Head Screw Driver
(Not Provided)







# STEP 8 C - 1 × 4 E - 1 × 4













STEP 11 D- > × 2 E- - × 2 K- - × 2 L- - × 2







WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.





#### Children have died from furniture tipover.

- ALWAYS secure it with an anchor device. NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.



This is a permanent label. Do not remove!

#### TOPPLING FURNITURE WARNING:

- ALWAYS secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent
- children climbing. Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).