



90 mm

**anko****K: 43555482 | T: 71011288 (Model: JLR-80615)****Magnetic Wireless Charging Pad  
Instruction Manual**


This is a smart phone wireless charger that allows you enjoy the fun of digital products easily.  
Please kindly read the user manual before using and keep it for future reference.

**Safety Notes**

1. Do not squeeze or collisions.
2. Do not disassemble or throw into fire or water, to avoid causing a short circuit leakage.
3. Do not use wireless charger in severely hot, humid or corrosive environments, to avoid circuit damage and occurs leakage phenomnon.
4. Do not place too close with magnetic stripe or chip card ( ID card, bank cards, etc. ) to avoid magnetic failure.
5. Please keep the distance at least 20cm between implantable medical devices ( pacemakers, implantable cochlear, etc. ) and the wireless charger, to avoid potential interference with the medical device.
6. To take care of the children, to ensure that they won't play the wireless charger as a toy, to avoid unnecessary accidents.

**Connect to Power Adapter**

- ① Connect the power adapter to socket.
- ② Plug the Type-C cable of the charging pad into the adapter.

**Charging Mode****Notes:**

1. Make sure the wireless charger dock connect to the power supply.
2. Put the magnetic wireless charging phone one the charger, they will align automaticly.

**Specification:**

Input: 5V~3A, 9V~2.22A

Output: 5W/7.5W/15W(Max.for iPhone)

**12 Month Warranty**

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**MADE IN CHINA****CUSTOMER SERVICE:****KMART AU: 1800 124 125****KMART NZ: 0800 945 995****TARGET AU: 1300 753 567**

65 mm