100mm

anka

WIRELESS CAR CHARGING PAD
User Manual
EWL-24502-A
K: 43-559-398 | T: 71-039-091

1. Device lay-out



2. Includes

(1) Wireless Car Charging Pad

(2) User Manual

3.Technical specifications

USB-A input: 5V=2A 9V=2A 12V=2A Mobile phone wireless charging output:

5W/7.5W(iPhone)/10W/15W MAX >7.5W Max for compatible iPhone

>10W Max for compatible Samsung smartphone

>15W Max for other compatible Android models

Charging efficiency: ≤75%
Transmission distance: ≤6MM

 5V=2A is minimum input for operation, the maximum output is 5W.

•When the input is 9V=2A, the maximum output is 10W.

•When the input is 12V=2A, the maximum output is 15W.

4.Operation

(1)Using attached USB-A cable plug in suitable wall charger(sold seperately).

(2) Place your wireless charging enabled device on the charging pad to start charging.

Please pay attention to aligning the phone coil with the product coil position to avoid the phenomenon of not charging. (3)If a foreign object (metalware) is placed on the charging pad,the wireless charging function will stop, and the foreign object needs to be removed. Please note that if phone case has a metal bracket or metal parts at the coil position, it will trigger the foreign object detection function, causing the phone to fail to charge.

5. Notes

(1)Do not disassemble or throw it into fire or water to avoid damage

(2)Do not use the wireless charger in extremely hot, humid, or corrosive environments, to avoid circuit damage and leakage.

(3)Do not place it too close to magnetic stripe or chip cards (ID cards, credit cards, etc.) to avoid magnetic interference or data loss.

(4)Please keep a distance of at least 30cm between implantable medical devices (pacemakers, implantable cochlear devices, etc.) and the wireless charger to avoid potential interference with the medical device.

(5) To ensure the safety of children, make sure they do not play with the wireless charger as a toy.

(6) Make sure there is no metal foreign object between the charging pad and the phone when charging.

* 12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warrantu.

This warranty will no longer apply where the defect is a result of alteration. accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
mart Australia Ltd. :/- Customer Service Centre	Target Australia Pty Ltd C/- Customer Service Centre

690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au 2 Kendall Street, Williams Landing. Vic,3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact—us

110mm

