

14mm



PLASMA BALL USB CAR CHARGER K: 43-660-028 | T: 71-045-139 Model: EB400885 Input: DC 12-24V--2A MAX



Output: USB-C: 5V=3.1A (15.5W MAX) USB-A: 5V=3.1A (15.5W MAX) USB-A: 5V=3.1A (15.5W MAX) USB-C+USB-A: 5V=3.1A (15.5W MAX) Adde In China Footory Code: F103110 Batch Code: 04/25



Rating Label Position:





PLASMA BALL USB CAR CHARGER

Instruction Manual



K: 43-560-028 | T: 71-045-139 MODEL: EB400885 MADE IN CHINA

105mm

CUSTOMER SERVICE:


KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567

Product Overview

1 Plasma Ball

2 USB-C Output port

3 USB- A Output port



Specification

Input: DC 12-24V == 2A MAX

USB-C: 5V == 3.1A (15.5W MAX) USB-A: 5V == 3.1A (15.5W MAX)

USB-C+USB-A: 5V === 3.1A (15.5W MAX)

Dimensions: 146.98 x 45 x 45mm

Operation

Connect power: plug the car charger into car socket.

Charging: Connect one end of charging cable to your device's charging port.

Caution

Do not hold the ball to pull or twist the charger out of car socket, it may lead to the air inside of the ball leak or damage. To prevent fire or electric shock, keep away from liquids and moisture.

Do not operate this car charger with a damaged plug. This car charger is not intended for use by children. Adult supervision is always required when children are present.

In case of emergency, discontinue use immediately.

For example:

> Smoke from the unit

> Changed shape

Warning

Please read the instruction manual before using this device and follow all the safety instruction to avoid damage caused by improper use.

- Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- 2) Use this device solely for its intended purpose.
- 3) Keep the appliance away from all hot surfaces and naked flames.
- 4) Always put the appliance on a level, stable, clean, dry surface.

 5) Protect the appliance from extreme best and cold dust direct.
- 5) Protect the appliance from extreme heat and cold, dust, direct sunlight, humidity and drops or jets of water.
- 6) Do not immerse the appliance in water or in other liquids.
- 7) Do not open the housing under any circumstances.
- 8) Do not introduce any objects into the interior of the housing.
- 9) Should the device malfunction due to electrostatic discharge or a short power surge, disconnect it.

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warrenty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.