


Instruction Manual Car Cleaning Brush


Keycode: 43560363



Presentations For Connection Way:


1. Connect the Water Supply

Attach your own garden hose (not included) to Port A, and connect the other end to your faucet.




2. Set Up the Brush Attachment

- First, connect the hose (with a quick connector) to Port B.
- Then, connect the brush handle (Joint C) to Port B using the quick-connect system.
- Use the black button (Joint D) to control the water flow.
 - When the button is aligned straight, the water is on.
 - Rotate the button 90° to turn the water off.




3. Add Detergent

- Unscrew the detergent bottle (Fitting G).
- Pour in your preferred car cleaning detergent.
- Screw the bottle back on securely.




4. Activate the Brush

- Turn on your water tap to allow water to flow through the brush.
- The rotating gear inside the brush head will begin to spin automatically.



5. Adjust Detergent Flow

- Use the dial knob to control how much detergent is mixed with the water—adjust according to your cleaning needs.




6. Use the Main Handle Separately (Optional)

- You can unscrew the main handle (Part E) to use it for rinsing off detergent or even for watering plants.

7. Choose Handle Length (Optional)

- Based on your preference, you can use 1 or 2 handle extensions for extra reach.
- Please refer to the final image in the manual for guidance on attaching the extension handles properly.



General Warnings & Precautions

Adult supervision required. This product is not a toy and should be kept out of reach of children.
Do not use with hot water exceeding 40°C (104°F) to avoid damage to the brush or hose connectors.
Use only mild detergents. Avoid harsh chemicals, solvents, or bleach, as they may damage the materials or affect surface finishes.
Ensure all connections are secure before turning on the water supply to prevent leaks or accidental disconnection.
Avoid applying excessive pressure while cleaning to prevent scratching vehicle surfaces or damaging the brush head.
Always turn off the water and release pressure before detaching any parts or storing the product.

Care & Maintenance Instructions

Rinse thoroughly with clean water after each use to remove detergent residue and dirt.
Drain and dry all parts before storing to prevent mould or material degradation.
Store in a cool, dry place away from direct sunlight or heat to prolong product life.
Check and clean the rotating mechanism periodically to ensure smooth operation.
Inspect connectors and valves for wear or cracks before each use; replace if damaged.

MADE IN CHINA