

# Assembly Instructions















## 43560400/43566143 BAILEY BEDSIDE TABLE





**WARNING:** DO NOT STAND, SIT OR LEAN ON THIS UNIT. DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE. KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. USE ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.

**CARE INSTRUCTIONS:** TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE. WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR AND DOMESTIC USE ONLY.


**MAXIMUM SAFE LOAD:10KG FOR TOP PANEL, 5KG FOR EACH DRAWER.**

### ① Hardware List














	A	M6x35mm	16pcs
	B	Ø15x9mm	16pcs
	C	Ø6x30mm	16pcs
	D	M4x35mm	12pcs
	E	M4x40mm	2pcs
	F	M7x40mm	4pcs
	G		1pcs
	H		4pcs
	I	M3x16mm	4pcs
	J		1pcs
	K		1pcs
	L	M3x12mm	28pcs
	M	Ø8x30mm	4pcs
	N		4pcs

	CL		2pcs
	CR		2pcs
	DL		2pcs
	DR		2pcs





### ②




3


			
① 1PC	② 1PC	③ 1PC	④ 1PC
			
⑤ 1PC	⑥ 1PC	⑦ 1PC	⑧ 4PCS
			
⑨ 2PCS	⑩ 2PCS	⑪ 2PCS	⑫ 2PCS
			
⑬ 2PCS			

## STEP 1:



-  A x 4
-  L x 16
-  CL x 2
-  CR x 2




Tool required  
Philips Head Screw Driver  
(Not Provided)



## STEP 2:


-  B x 4
-  C x 2



Tool required  
Philips Head Screw Driver  
(Not Provided)




## STEP 3:


-  A x 4



Tool required  
Philips Head Screw Driver  
(Not Provided)

## STEP 4:

-  B x 4
-  C x 6
-  E x 2




Tool required  
Philips Head Screw Driver  
(Not Provided)




## STEP 9:


 D x 8



x 2

  
Tool required  
Phillips Head Screw Driver  
(Not Provided)


## STEP 10:




x 2

## STEP 11:



 A x 8




x 2


  
Tool required  
Phillips Head Screw Driver  
(Not Provided)

## STEP 12:




 B x 8  
 C x 4




x 2

  
Tool required  
Phillips Head Screw Driver  
(Not Provided)

## STEP 13:


-  L x 12
-  DL x 2
-  DR x 2



x 2


Tool required  
Philips Head Screw Driver  
(Not Provided)

## STEP 14:




## STEP 15:

-  K x 1



Tool required  
Philips Head Screw Driver  
(Not Provided)

## ⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.
- Furniture type is at risk of toppling over.

NEVER put a TV  
on this furniture



This is a permanent label. Do not remove!

### TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE  
YOUR FURNITURE WITH  
THE SUPPLIED WALL FIXING.  
SCAN THE CODE FOR  
MORE INFORMATION.

