


21cm

## Camp Kitchen



1. Product removal.



2. Pull the product to the right and left to open.



3. After opening, carefully pull out the table leg fixing connector to secure the leg in place.



4. The product is mounted on a cloth cabinet and secured with upper and lower aluminum alloy plates. Fix both tray boards in place.

THIS PRODUCT IS FOR OUTDOOR CAMPING USE ONLY  
TO BE ASSEMBLED BY AN ADULT & USED UNDER ADULT SUPERVISION.

### WARNING!

Use only on firm and level ground to ensure work surface is level.  
Take extra care with folding parts & the assembly of the item.  
Ensure all locking mechanisms are secure before use.  
Do not use in wet conditions & take care to wipe any spills immediately  
**KEEP DRY**

### CARE INSTRUCTIONS:

Spot clean with mild soapy water, allow fabric to dry naturally & wipe surfaces dry. Do not use bleach, acids, solvents or abrasive cleaners. Store in a cool, dry place when not in use.



5. Finally, install the windshield and place the shelf board inside the cabinet. Your camp kitchen is now ready to use.



KEEP AWAY  
FROM FIRE



MAX LOAD  
WEIGHT

Made in China