anko

mm

—

Bone Conduction Bluetooth Headphones Instructions Manual K: 43567423 | T: 71053912 (Model: JLR-80571)



The photos and illustrations shown in this instruction manual are generic. The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.

Packing list:

Headphone x 1, USB-C Charging Cable x 1, Manual x 1

Please read all the information carefully before you use the product and keep the manual for future reference.

Product Structure



Specification:

Bluetooth version: 5.4 Battery: 220mAh (Rechargeable Li-ion battery) Driver Unit: 16.2mm Impedance: 80hm Sensitivity: 90dB ± 3dB Working distance: 10M (no obstacles) Working time: approx. 8 HOURS AT 80% VOLUME Charging time: approx. 2 HOURS Input rating: 5V, 300mA

How to Wear

1. Hold the headphones with both hands, and place the headphones around the back of your neck as picture



2. Ensure the headphones make firm but gentle contact with your temporal bones in front of your ears as picture—this is where sound vibrations travel best.



3. Shake your head lightly to test stability—the headphones should stay in place without slipping.

Bluetooth connection

Follow the steps: 1. Turn on the headphone, the indicator flashes alternately with blue and red, the headphone enter the pairing status.

2. Activate the Bluetooth function and se "anko43567423" referring to your phone 3. Manually click "anko43567423" to con 4. The indicator will turn off after connected successfully.

Note:

> Please make sure that your phone is built-in Bluetooth function

> The headphone can automatically enter pairing status after power on if there is no re-connection.

device that you had paired. To re-connect, you just need to turn it on.

> The blue light will flash once every several seconds during playing

Operating instruction

Power ON/OFF

Long press 也 button to turn on /off the device.

Music Playing

Function	Headphone Status	Operatio
Increase		0
volume		Short pres
Decrease		
volume	Play Music	Short pres
Next song	Play Music	Long pres
Previous		Long pres
Pause/P l ay		Short pres

80 mm

80 mm

earch for	
e instructions.	
nnect.	
sted successfullu	

> As the headphone can automatically reconnect with the last

on
ss "+"
ss ""
s "+"
s "-"
ss ${f U}$ to switch pause/play

Phone calls					
Function	Headphone Status	Operation			
Answer / hang up		Short press ${f U}$ to answer/hang up			
Decline	phone calls in	Long press U to decline			
Volume control	Calling	Short press "+"/ "-" to increase/ decrease			

Al intelligent voice control

Function	Headphone status	Operation
Voice control	Bluetooth is connected	Double click 也

› Double click ひ under Bluetooth connection status, and after hearing the prompt, you can control the phone by voice. > It only works with phones supporting voice wake-up function

To charge the headphone

> As product is built-in non-removable and rechargeable battery, please use the provided charging cable to charge; \rightarrow Please charge the product with the input power below 5V/1A; > Fully charge the product before the first use. It takes 2 hours to charge for the subsequent use; > The LED indicator lights up red during charging and turns blue when charging is complete.

> Please choose the charger that is certified by the regular manufacturer:

> The battery performance may decrease as repeating charging and using the product. It's a normal phenomenon for all rechargeable batteries.

> Regular charging the headphone for every month is to ensure the life of the headphone, while pro-longed period of idle or low battery level may lead to battery life issue.

> Only use the charging cable provided to charge the headphone, and the cable should not be used for charging other device.

> Built-in battery is not removable and replaceable, if damaged should contact service and repair.

Trouble shooting

Unable to boot	Check whether the headset is fully charged. Check whether the buttons are operated by mistake.
Unable to connect to Bluetooth	Check if the indicator is flashing with red and blue alternately. If the blue light is breathing on, it means the headset is connected to another device and you need to disconnect the currently connected device.
Unable to reconnect	Check if the device's Bluetooth is turned on.
Volume is low	Check if need to increase the device's volume. Check if the wearing way is correct.

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in

accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE: KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567