


120mm

120mm

anko

## Instruction Manual



### MEMBRANE WIRED 3 COLOUR KEYBOARD

K: 43-567-478 | T: 71-054-186

Model No: EB400801

#### Specifications:

Key number: 94

Multi Media Keys: 4, control music and volume

Interface: USB

Dimension: 384.5 x 150 x 35mm

Weight: 547g

Support Windows 98/Me/2000/XP/Vista/7/10, Linux

Cable length: 1.5m

#### How To Use:

1. Turn on your computer.

2. Insert the USB interface of keyboard into a USB port of your computer (better choose the USB port located on the back of the chassis instead of those on the front).

3. Wait for 1 minute, and your keyboard will automatically read by your computer with no extra driver needed.

(Note: This is a plug & play keyboard, no need for the use of a driver.)






















Status Indicator: "Num Lock", "Caps Lock", "Win".

4. Num Lock function

With the Numlock key turned on and the Nums indicator light on, the keys of the keypad are used to enter numbers.

With the Numlock indicator off, the keypad keys are used to move the cursor (Up/down/left/right, page up/page down) and the delete function, etc.

#### Keyboard Function:

Fn+	 F1	 F2	 F3	 F4	 F5	 F6
	Media	Volume-	Volume+	Mute	Stop	Prev Track
	 F7	 F8	 F9	 F10	 F11	 F12
	Play/Pause	Next Track	Mail	WebHome	KBLock	Calculator
						
	Light Breath	Light Up	Light Down	Breath Slow	Breath Quick	
	 ↑	 ↓	 ←	 →		
	Up	Down	Left	Right		

#### 12 Month Warranty:

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567