anko

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE: KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567

K: 43567621 | T: 71054490(Model: JLR-79870)

Wired Pro Gaming Headset Instructions manual


includes:

→ Headset




Please read the safety instruction carefully before using the product for the first time and keep the instruction for future reference.

Function overview:



Removable microphone installation



Plug the removable microphone into the microphone jack. Noted: If the microphone doesn't work, pull out the removable microphone, then plug into the microphone jack again.

How to use this headset

Function Operation Power ON / OFF

Plug 3.5mm plug and USB plug in/out your device

Volume + / -

Rotate the switch to increase or decrease the volume

Microphone ON / OFF

Slide the switch to turn on /off the microphone

LED Light

Insert the USB plug into a power source, and the LED will turn on

Specifications:

SpeakerMicDriver Unit:Mic Unit:50mm6 mm

 $\begin{array}{lll} \mbox{Impedance:} & \mbox{Impedance:} \\ \mbox{16\pm15\%Ohm} & \mbox{≤ 2.2 K Ω} \end{array}$

Sensitivity:Mic Directivity:110±3dB at 1KHzOmnidirectional

Frequency Response:20Hz-20KHz

Sensitivity:
42±3dB

Rated Power:20mw

Frequency Response:
100Hz-10KHz

Cable Length: 2.2M

Plug Type: 3.5mm+USB

WARNING Do not dispose of unit in fire or water.>Never attempt to disassemble and reassemble.>Waste electrical products should not be disposed of with household waste, please recycle where facilities exist.>Check with your local authority for recycle advice.>Keep your device and all accessories out of the reach of children and animals.>Small parts may cause choking or serious injury if swallowed.>Avoid exposing your device to very cold or very hot temperatures below 0 'C or above 45 °C).>Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device.> Do not allow your device to get wet as liquids can cause serious damage.>Do not handle your device with wet hands.