


120mm

90mm

anko

Instruction Manual



WIRED GAMING MOUSE

K: 43567652 | T: 71054513

Model No: EB400685

MADE IN CHINA

Please read all the information carefully before you use the product and keep the manual for future reference.

Specifications:

DPI: 1200(default)~1800~2400~3600.

Input rating: 5V 100mA


Simple and classic design, great for home & office use.

USB plug & play.

Connect the USB cable to your computer's USB port.

Compatible with Windows 98/2000/XP, Windows 7/8/10, Vista system, Mac OS system.

Product Structure:



- 1 Left button
- 2 Right button
- 3 Middle button
- 4 DPI button
- 5 Sensor
- 6 Foot Pad

Safety Instructions:

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

- › Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
 - › Use this device solely for its intended purpose.
 - › Only use this appliance indoors.
 - › Keep the appliance away from all hot surfaces and naked flames.
 - › Always put the appliance on a level, stable, clean, dry surface.
- Protect the appliance from extreme heat and cold, dust, direct sunlight, humidity, and drops or jets of water.
- › Do not immerse the appliance in water or other liquids.
 - › Do not open the housing under any circumstances.
 - › Do not introduce any objects into the interior of the housing.

12 Month Warranty:

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic, 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us