

80*90cm 书纸，折页， 正反面印刷

<div data-bbox="289 213 577 298"></div> <div data-bbox="275 314 596 360"><p>NOVELTY SPORT CAR SPEAKER Instruction Manual</p></div> <div data-bbox="298 377 573 428"><p>K: 43573295 I T: 71077581 Model: OS-2205</p></div> <div data-bbox="279 491 585 684"></div> <div data-bbox="155 773 716 809"><p>To ensure correct operation and avoid damage, please read this user manual carefully before using this product and retain for future use.</p></div>	<div data-bbox="753 196 934 273"><p>Includes: 1 x Speaker 1 x USB-C charging cable 1 x Instruction Manual</p></div> <div data-bbox="1014 196 1054 259"></div> <div data-bbox="753 304 1092 456"><p>Specification:</p><ul style="list-style-type: none">• Bluetooth version : 5.4• Material: ABS+PC+Iron mesh• Battery: 3.7 V 1200mAh Li-ion battery• Speaker: 1x8W 66mm 4Ω• Function: BT/TF/USB• Dimension: 331x140x90mm• Car headlight</div> <div data-bbox="753 505 1220 544"><p>Functional Buttons: The functional buttons are located at the rear of the car speaker</p></div> <div data-bbox="905 567 1173 719"></div> <div data-bbox="753 741 1176 818"><div><p>① Volume up/Next track</p><p>② Play/Pause/Mode button</p><p>③ Volume down/Previous track</p><p>④ ON/OFF button, Light button</p></div><div><p>⑤ Charging port</p><p>⑥ TF card slot</p><p>⑦ USB slot</p><p>⑧ Indicator light</p></div></div>	<div data-bbox="1360 196 1892 292"><p>Pairing: When turn on the speaker, a sound will indicate Bluetooth mode. Activate the Bluetooth feature on your source device, and set it to search. Wait for your new speaker " KM43573295" to appear, then select to pair and connect.</p></div> <div data-bbox="1360 343 1780 401"><p>ON/OFF Button: Long press the ON/OFF button to turn on/off the speaker. Short press to turn on/off the light.</p></div> <div data-bbox="1360 452 1749 508"><p>Play/Pause/Mode Button: Short press the button to play or pause the music. Long press the button to change to BT/USB/TF mode.</p></div> <div data-bbox="1360 560 1621 616"><p>Volume up/Next Button: Short press to change to next music Long press to increase the volume</p></div> <div data-bbox="1360 667 1652 724"><p>Volume down/Previous Button: Short press to change to previous music Long press to decrease the volume</p></div>
<div data-bbox="147 929 720 1064"><p>TF card & USB mode: Insert the TF card (Not included) card or USB drive (Not included) into the slot. Music will play automatically when there are MP3 files stored. Press and hold the "+" and "-" buttons for volume control. Also short press the same buttons for track selection. TF card (Not included): Max. memory of 32GB USB drive (Not included): Max. memory of 32GB</p></div> <div data-bbox="147 1113 726 1228"><p>Charging: Connect the small end of the charging cable (included) to the charging port located on the speaker. Connect the larger end of the cable to your computer's USB port or an AC adaptor(not included). The LED indicator will turn red while charging. Once fully charged, the red LED will turn off.</p></div> <div data-bbox="147 1277 707 1525"><p>Caution</p><ul style="list-style-type: none">• Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.• The battery is not replaceable. Replacement of a battery can result in an explosion or the leakage of flammable liquid or gas.• Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.• Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.• A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.• The marking is located on the bottom of the apparatus.</div>	<div data-bbox="753 929 1325 1064"><p>12 Month Warranty Thank you for your purchase. Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer</p></div> <div data-bbox="753 1087 1295 1123"><p>For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.</p></div> <div data-bbox="753 1147 1316 1241"><p>We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.</p></div> <div data-bbox="753 1265 1323 1356"><p>Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.</p></div> <div data-bbox="753 1380 1312 1492"><p>Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.</p></div>	<div data-bbox="1360 929 1902 988"><p>The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.</p></div> <div data-bbox="1360 1038 1585 1149"><p>MADE IN CHINA CUSTOMER SERVICE: KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567</p></div> <div data-bbox="1656 1487 1890 1504"><p>WARNING: THIS IS NOT A TOY</p></div>