

6+
years



















2-4
Players

ARCADE

GAMES TABLE


Instructions

Components:

A GREEN  x 1	B BLUE  x 1	C  x 2	D  x 2
E  x 4	F  x 4	G  x 16	H  x 8
I  x 8	J  x 4	K  x 4	L  x 4
M  x 2	N  x 2	O  x 1	P  x 2
Q  x 1	R  x 2		


Assembly Instructions:

①




Align the long wood panel (D) horizontally with 2 short side panels (C). Secure them using corner pieces (E&F) and ensuring all grooves are precisely matched.

②




After securing the three sides, flip the assembly vertically and rest it on the long panel (D). Slide the centre playing board (O) into the grooves (refer to Diagram 2). Please note: ensure all grooves are fully engaged before flipping.

③




First, attach Component G to either Pole A or B. Then position Group A and Group B poles opposite each other, facing the required direction.

④




⑤




Recommended: Two-person team for stability. While one person holds the centre playing board and wood panel steady, another attaches the bottom corner pieces (E&F) as illustrated in Diagram 5. Safety Note: Ensure all corner pieces are fully secured before releasing support.

⑥




⑦




Two-person operation mandatory. Person A: Slides air hockey goal (M) upward from table underside. Person B: Aligns football goal (N) downward from table top. Please note: Simultaneously press the back tab and primary side tab, then insert both tabs into N's base groove. And audible "click" indicates proper seating.


⑧



Assembly Instructions:



AIR HOCKEY TABLE ASSEMBLY INSTRUCTIONS



01. FOOTBALL

Number of Players: 2-4

Game Setup & Rules:

1. Place the game board on a flat and stable surface, ensuring it is clean and free of obstacles..

2. Each player selects a side and holds the control rods to manoeuvre their team's players.
3. Decide which player starts first by flipping a coin (not included) or another fair method.
4. The game starts with one player serving the ball by placing it in the centre of the football table.
5. Players rotate and push the rods to pass, defend, and attempt to score by kicking the ball into the opponent's goal.
6. A goal is scored when the ball completely enters the opponent's goal.
7. The ball is then placed back in the centre, and the player who conceded the goal restarts the game.
8. Players can set a target score (e.g. 9 points) or play within a time limit (e.g. 5 minutes), with the highest-scoring player winning when time runs out.
9. After each game, players should switch sides of the football table before starting a new match.

Fouls:

1. Excessive spinning of the control rods (over 360°).
2. Lifting or moving the table intentionally.
3. Touching the ball with hands (unless the ball is stuck, and both players agree to restart the play).

02. AIR HOCKEY

Number of Players: 2

Game Setup & Rules

1. Place the game board on a flat and stable surface, ensuring it is clean and free of obstacles.
2. Each player stands on one side of the rink and holds a pusher.
3. Before starting, check that the puck's bottom switch is ON.
4. Decide which player starts first by flipping a coin (not included) or another fair method.
5. Players use their pushers to hit the puck, aiming to score while defending their own goal.
6. When the puck enters a goal, the scoring player earns one point, and the game restarts from the centre.
7. Players can set a target score (e.g. 9 points) or play within a time limit (e.g. 5 minutes), with the highest-scoring player winning when time runs out.
8. After each game, players should switch sides of the air hockey table before starting a new match.
9. Once the game is over, turn off the puck to conserve energy.

Fouls:

1. Players must not touch the puck with their hands to interfere with gameplay.
2. Strikers should not be lifted or slammed too hard to avoid damaging the equipment or causing injury.
3. If the puck flies off the table, the last scoring player restarts the game.

Battery Usage Instructions :

Game Setup & Rules:

This product requires 2 × AAA batteries (batteries not included).

Installing Batteries:

1. Battery installation or replacement must be performed by an adult.
2. Open the battery compartment cover (a screwdriver is required, not included).
3. Insert the batteries correctly according to the polarity markings (+/-) inside the compartment.
4. Close the battery compartment cover and screw it properly.

Replacing Batteries:

1. Replace all 2 batteries with new ones when the product slows down or stops working.
2. Do not mix old and new batteries or different types of batteries.
3. Use the same brand and model of batteries for optimal performance.

Safety Precautions:

1. Do not attempt to recharge non-rechargeable batteries.
2. Do not mix carbon, alkaline, or rechargeable batteries.
3. Do not dispose of batteries in fire to avoid explosion or leakage.
4. Do not short-circuit the battery terminals to prevent hazards.
5. Remove the batteries if the product will not be used for an extended period to avoid battery leakage.
6. If battery leakage occurs, stop using the product immediately, wipe the battery compartment clean with a dry cloth, and avoid contact with leaked substances.

Environmental Protection & Disposal:


Dispose of used batteries properly according to local regulations to prevent environmental pollution.

Adult assembly required.

Please keep instruction manual for future reference.



REQUIRES 2 X 1.5V AAA BATTERIES
(NOT INCLUDED).



WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES.

NON-RECHARGEABLE BATTERIES ARE NOT TO BE CHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED BY AN ADULT. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERY FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.



WARNING:

CHOKING HAZARD - SMALL PARTS AND SMALL BALLS.
NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

43-577-378

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567

