

12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation. We will provide you with your choice of a refund, repair(where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period.

The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/-Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service:1800 124 125 (Australia)or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/-Customer Service Centre 2 Kendall Street,Williams Landing, Vic 3027 Customer Service:1300 753 567 Or via Customer Help at target.com.au/help/contact-us

BRIGHTS LED COSMETIC CASE & LIP GLOSS SET Instruction Manual

Content:

10 x Lip Gloss,

1 x Cosmetic Case With LED Rechargeable Mirror,

1 x Micro - USB Charging Cable



Specifications:

Input: 5V DC 1A

Input power: 5W

Battery capacity: 3.7V 1000mAh Li-ion Battery (non-replaceable)

Duration of use: 3 hours


Charging time: About 3.5 hours

Product Profile:



① Lid/Mirror


② Silicone handle



③ Cosmetic Case

④ LED mirror

⑤ Dimmable LED



⑥ Switch

⑦ adjustable stand



How to use the LED mirror:

1. Open the lid of the cosmetic case.
2. Peel off the plastic film from the mirror before use.
3. Long press the switch on the mirror to turn on the light.
4. When the light is on, long press the switch to adjust the brightness of the light.
5. Adjustable stand on the back of the mirror can be adjusted to extend in desired stand position and put on flat surface or inserted in the case.
Note: A 'click' sound exists when adjusting between different stand positions.
6. Short touch the switch to turn off the light when the product is no longer in use.

Warning:

1. This appliance is not intended for use by persons(including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. The appliance must only be supplied by AS 61347.2.13 certified SELV power supply with output 5V DC 1A.
4. When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
5. For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
6. Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
7. Use a dry microfiber cloth to clean the appliance.
8. Operate and store carefully to ensure the product does not incur damage by being dropped.
9. Do not leave the product in excessive heat or high temperatures as it can cause the product to malfunction.
10. The LED light is non-replaceable.
11. For indoor use only. This is not a toy. Keep away from children.
12. This product is not to be directly connected to the mains supply.
13. The light source of this luminaire is not replaceable; when the light source reaches its end of life, the whole luminaire shall be replaced.
14. This appliance contains battery that is non-replaceable.
15. The appliance must be rested on a flat, stable surface.
16. This product should only be charged using the micro-USB charging cable supplied.
17. Warning: This product contains small magnets. Swallowed magnets can stick together across intestines causing serious injuries. Seek immediate medical attention if magnets are swallowed.

How to charge:

1. Turn the appliance off.
2. Plug the USB cable into a USB power source and the other end into the charging port on the appliance.
3. The charging red indicator light beside the charging port will light up when charging, and the indicator light changes to green when fully charged.



Charging indicator light

Safety instructions for Li-ion battery:

1. Monitor device while charging.
2. Charge battery in an isolated area.
3. Keep away from flammable materials.
4. Do not expose to direct sunlight.
5. Do not disassemble, modify, heat, or short-circuit the battery.
6. Do not drop or subject to strong impacts. Only charge the battery with charging cable provided. In the unlikely event of leakage or explosion, use sand or chemical fire extinguisher for the battery.
7. Battery must be recycled or disposed of properly.