INSTRUCTIONS FOR STICKY GOLF COURSE

Keycode: 43-598-373

Important Information:

- Adult assembly is recommended.
- Check all parts and accessories before each use.
- Do not aim balls at eyes or faces.
- Contains small parts and balls. Not suitable for children under 5 years.
- Hooks adhere best to clean, hard, dry, and smooth surfaces. Remove any leftover adhesive with a damp cloth.

Indoor Play & Outdoor Play:

Play this game anywhere! This golf game set mat is perfect for both indoor and outdoor use on a variety of surfaces. It comes with ground stakes, making it ideal for placement on grass or sand. Additionally, it can be hung on a wall to serve as a ball toss or dart game. You can also hang it on an outdoor fence, garage beam, or ball net for versatile play options.



Game rules:

- 1. different colored balls can be used to group up to four groups.
- 2. assemble adjustable golf club:
- a. screw and tighten handle & head to be golf club for kid.
- b. screw and tighten handle & middle & head to be golf club for adult.
- 3. put the ball on the golf hitting mat, swing the club to target the mat.
- 4. use the scoreboard to record each person's score.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567